

Function		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1–16 1–16	1–16 1–16	
Mode	Default Messages Altered	3 × –	1, 3 × –	
Note Number	True voice	*21–108 –	0–127 *0–127	
Velocity	Note ON Note OFF	○ × (9nH: V=0)	○ ×	
After Touch	Key's Ch's	× ×	× ×	
Pitch Bend		×	○	
Control Change	01	×	**○	modulation data entry volume (part) pan part expression sustain pedal sostenuto pedal soft pedal reverb depth digital effect NRPN LSB, MSB RPN LSB, MSB
	06,38	×	**○	
	07	×	**○	
	10	×	**○	
	11	×	**○	
	64	○ ×	○ ×	
	66	×	○ ×	
	67	×	○ ×	
	91	×	**○	
	93	○ ×	○ ×	
	98, 99	×	**○	
	100,101	×	**○	
Prog Change	True #	○ × 0–127	○ × 0–17	
System Exclusive		×	×	
System Common	Song Pos Song Sel Tune	×	×	
		×	×	
		×	×	
System Real Time	Clock Commands	×	×	
		×	×	
Aux Messages	Local ON/OFF All Notes OFF Active Sense Reset	×	○	
		×	○	
		○	○	
		×	×	
Notes		○ × Whether or not the data for each of these items is transmitted or received can be set. * Changes depending on the TRANPOSE setting. ** Effective only in the MULTI TIMBRE mode.		

Mode 1:	OMNI ON, POLY	Mode 2:	OMNI ON, MONO	○ : Yes
Mode 3:	OMNI OFF, POLY	Mode 4:	OMNI OFF, MONO	× : No