


### Display

The display shows a variety of different setting values.

- During normal playing, it is turned off.



### TOUCH SENSITIVITY

The keyboard touch (Touch Response) can be changed to match your type of playing.

- Choose from **LIGHT**, **NORMAL** and **HEAVY**.

The unit is in the standby condition when the AC adaptor is connected. The primary circuit is always "live" as long as the AC adaptor is connected to an electrical outlet.

- When leaving the product unused for a long time, turn off the **PLAY** button of the unit and pull the AC adaptor out of the socket for power saving. (The product consumes a power of 3 W even with the **PLAY** button of the unit turned off.)

### Music stand

Insert the music stand in the two holes on the rear panel.