SECTION VI
E-SERIES PARTS LIST

INDEX

CONTROL PANEL ASSEMBLY (E100)	120-000015	6–6
Control Switch Base & Support Assembly		6–6
Control Panel Assembly (Left Hand)		6–6
Control Panel Assembly (Center)		6–6
Control Panel Assembly (Right Hand)		6–6
PERCUSSION SWITCH ASSEMBLY #1	008-027641	6–6
Switch Panel & Bracket Assemblies		6–6
Control Tabs		6–6
PERCUSSION SWITCH ASSEMBLY #2	008-027646	6–6
Switch Panel & Bracket Assemblies		6–6
Control Tabs		6–6
PRESET SWITCH ASSEMBLY (Upper)	008-027644	6–6
Switch Panel & Bracket Assemblies		6–6
Control Tabs		6–6
Cancel Linkage Assembly		6–7
PRESET SWITCH ASSEMBLY (Lower)	008-027643	6–7
Switch Panel & Bracket Assemblies		6–7
Control Tabs		6–7
Cancel Linkage Assembly		6–7
VIBRATO SWITCH ASSEMBLY	008-027645	6–7
Switch Panel & Bracket Assemblies		6–7
Control Tabs		6–7
VIBRATO VARIATIONS SWITCH ASSEMBLY	008-027647	6–7
Switch Panel & Bracket Assemblies		6–7
Control Tabs		6–7
REVERB & VOLUME SWITCH ASSEMBLY	008-027642	6–8
Switch Panel & Bracket Assemblies		6–8
Control Tabs		6–8
MANUAL STOP SWITCH ASSEMBLY (Left Hand)	120-000019	6–8
MANUAL STOP SWITCH ASSEMBLY (Right Hand)	120-000018	6–8
Mounting Block Assembly (Left Hand)		6–8
Mounting Block Assembly (Right Hand)		6–8
Contact Spring Assembly		6–8

MANUAL STOP SWITCH ASSEMBLY (Cont.)

Clamp Spring 6–8
Drawbar Stop 6–8
Stop Slide 6–8
Stop Channel 6–8
Stamped Stop Knobs 6–8

PEDAL STOP SWITCH ASSEMBLY 125-000026 6–8

Pedal Drawer Assembly (Left Hand) 6–8
Stop Slide Assembly (Left Hand) 6–8
Stop Channel 6–9
Stamped Stop Knob 6–9
#4-24 x 3/8" Round Head Tap Screw 6–9
Pedal Drawbar Assembly (Right Hand) 6–9
Stop Slide Assembly (Right Hand) 6–9
Stop Channel 6–9
Stamped Stop Knob 6–9
#4-24 x 3/8" Round Head Tap Screw 6–9
Cover Plate Assembly 6–9
Mounting Block 6–9
Plastic Gear 6–9
Potentiometer (Left Hand) 6–9
Potentiometer (Right Hand) 6–9
Bracket (For Mounting Potentiometer) 6–9
Matching Transformer Assembly (Manual) 6–9
Matching Transformer Assembly (Percussion) 6–9

PERCUSSION & REITERATION DRIVER ASSEMBLY 063-037568 6–9

Transformer Assembly 6–9
Concentric Potentiometer 6–9
Knob 6–9
Line Switch 6–9
Pilot Light Lens 6–9
Lamp 6.3V 6–9
Shielded Lead Assemblies 6–9
Output Cables 6–10

CONTROL PANEL ASSEMBLY (E200) 120-000016 6–10

Control Panel Assembly (Left Hand) 6–10
Control Panel Assembly (Center) 6–10

PERCUSSION SWITCH ASSEMBLY 008-028646 6–10

Switch Panel & Bracket Assemblies 6–10
Control Tabs 6–10

PRESET SWITCH ASSEMBLY (Swell Manual) 008-028647 6–10

Switch Panel & Bracket Assemblies 6–10
Control Tabs 6–10

VIBRATO SWITCH ASSEMBLY 008-028648 6–10

Switch Panel & Bracket Assemblies 6–10
Control Tabs 6–10

PRESET SWITCH ASSEMBLY (Great)	008-028649	6–11
Switch Panel & Bracket Assemblies		6–11
Control Tabs		6–11
Output Cables		6–11
Matching Transformer & Bracket Assembly		6–11
PERCUSSION & REITERATE DRIVER (E200)	063-037567	6–11
CONTROL PANEL ASSEMBLY (E300)	120-000027	6–11
Control Panel Assemblies		6–11
PERCUSSION SWITCH ASSEMBLY #1	008-030512	6–11
Switch Panel & Bracket Assemblies		6–11
Control Tabs		6–11
PERCUSSION SWITCH ASSEMBLY #2	008-030513	6–12
Switch Panel & Bracket Assemblies		6–12
Control Tabs		6–12
MATCHING TRANSFORMER & BRACKET ASSEMBLY (Manual)		6–12
MATCHING TRANSFORMER & BRACKET ASSEMBLY (Percussion)		6–12
PERCUSSION & REITERATE DRIVER ASSEMBLY	063-037566	6–12
Potentiometer		6–12
Knob		6–12
MANUAL ASSEMBLY (Upper-E100)	119-000020	6–12
Manual Frame Assembly		6–12
Key Comb Assembly (12 Key)		6–12
Key Comb Assembly (13 Key)		6–12
Natural Keys		6–12
Sharp Keys		6–12
MANUAL ASSEMBLY (Lower-E100)	119-000018	6–12
Manual Frame Assembly		6–12
Switch Cover Assembly		6–12
MANUAL ASSEMBLY (Upper-E200)	119-000019	6–12
Manual Frame Assembly		6–12
Switch Cover Assembly		6–12
MANUAL ASSEMBLY (Lower-E200)	119-000021	6–13
Manual Frame Assembly		6–13
Switch Cover Assembly		6–13
MANUAL ASSEMBLY (Upper-E300)	119-000031	6–13
Manual Frame Assembly		6–13
Switch Cover Assembly		6–13
MANUAL ASSEMBLY (Lower-E300)	119-000030	6–13
Manual Frame Assembly		6–13
Switch Cover Assembly		6–13

MANUAL ASSEMBLY (Cont.)

Front Strip (E100-E300) 6–13
Front Strip (E200) 6–13
Vibrato Line Assemblies 6–13
Cable Assembly (Generator to Manuals) 6–13
Sustain Keyer Cables 6–13
Manual Mounting Brackets 6–13
End Blocks 6–13

GENERATOR & MOTOR ASSEMBLIES 6–13

SYNCHRONOUS MOTOR ASSEMBLIES 6–13

GENERATOR ASSEMBLIES 6–13

VIBRATO SCANNER ASSEMBLIES 6–14

PEDAL SWITCH ASSEMBLY 116-000013 6–14

Switch Frame Assembly 6–14
Cable Assembly 6–14
Plastic Clamp 6–14
Felt (Down Stop) 6–14
Switch Cover 6–14

SWELL PEDAL ASSEMBLIES 6–14

Shutter Assembly 6–14
Light Bulb 6–14

HARP SUSTAIN KEYER ASSEMBLY (E100) 124-000052 6–14

Printed Wiring Board Assemblies 6–14

HARP SUSTAIN KEYER & PREAMPLIFIER 124-000050 6–15

HARP SUSTAIN KEYER ASSEMBLY (E200) 124-000053 6–15

REVERBERATION UNIT 121-000008 6–15

SPEAKERS 6–15

PEDAL DIVIDER ASSEMBLY 124-000051 6–15

Printed Wiring Board & Terminal Assembly 6–15

PREAMPLIFIER ASSEMBLY 117-000012 6–16

Percussion Board & Component Assembly 6–16
Preamplifier Board & Component Assembly 6–16
Plug Assemblies 6–17
Tubes 6–17

POWER AMPLIFIERS 6–17

Power Transformers 6–17

Filter Choke 6–17

Output Transformers 6–17

POWER AMPLIFIERS (Cont.)

Choke 6–19

Miniature Lamp 6–19

Tubes 6–19

CLICK FILTER ASSEMBLY 063-030225 6–19

Tuning Coil Assembly 6–19

BRUSH & CYMBAL BOARD ASSEMBLY 124-000020 6–19

MUSIC LIGHT ASSEMBLY (E262) 6–20

Fluorescent Lamp 6–20
Starter 6–20

WOODWORK 6–20

Cabinet Assemblies 6–20
Case Assemblies 6–20

PEDAL KEYBOARD ASSEMBLIES 6–21

BENCH ASSEMBLIES 6–21

PANEL & GRILLE CLOTH ASSEMBLIES 6–21

MISCELLANEOUS 6–21

CONTROL PANEL ASSEMBLY (E100)			120-000015
Control Switch Base & Support Assembly			061-027639
Control Panel Assembly (Left Hand)			061-030592
Control Panel Assembly (Center)			061-040644
Control Panel Assembly (Right Hand)			061-027632
PERCUSSION SWITCH ASSEMBLY #1			008-027641
Switch Panel & Bracket Assembly (Chimes, Guitar, Banjo)			008-027668
Switch Panel & Bracket Assembly (Marimba, Xylophone)			008-030044
Control Tab	CHIMES		031-037534
Control Tab	GUITAR		031-037535
Control Tab	MARIMBA		031-037536
Control Tab	XYLOPHONE		031-037537
Control Tab	BANJO		031-037538
Tubular Clip			013-028002
Shaft			020-037239
Mounting Bracket			035-024351
Lever Mounting Bracket			035-024335
Over Center Spring (Toggle Spring)			012-038938
Flat Head Machine Screw		5 used	839-040214
Sems Round Head Machine Screw		7 used	821-040314
Tie Strip			041-027176
Resistor	330K	R411	600-021091
Resistor	47Ω	R419	600-021561
Percussion Harmonic Cable			011-028641
PERCUSSION SWITCH ASSEMBLY #2			008-027646
Switch Panel & Bracket Assembly (Add Vibrato)			008-027670
Switch Panel & Bracket Assembly (Cymbal, Brush)			008-027671
Switch Panel & Bracket Assembly (Reiterate, Harp Sustain)			008-027679
Control Tab	(REITERATE)		031-037539
Control Tab	(HARP SUSTAIN)		031-037540
Control Tab	(ADD VIBRATO)		031-037541
Control Tab	(CYMBAL PEDAL)		031-037542
Control Tab	(BRUSH LOWER)		031-037543
Tubular Clip			013-028002
Shaft			020-037239
Mounting Bracket			035-024351
Lever Mounting Bracket			035-024335
Over Center Spring (Toggle Spring)			012-038938
Flat Head Machine Screw		5 used	839-040214
Sems Round Head Machine Screw		7 used	821-040314
Tie Strip			041-027176
Resistor	220K	R420	600-020331
Resistor	33K	R412, R413	600-020851
PRESET SWITCH ASSEMBLY (UPPER)			008-027644
Switch Panel & Bracket Assembly (Strings 8', Full Tibias 16', Theater Brass 16')			008-027674
Switch Panel & Bracket Assembly (Drawbars & Percussion)			008-027667
Control Tab	(DRAWBARS & PERCUSSION)		031-037524
Control Tab	(STRINGS 8')		031-037525
Control Tab	(FULL TIBIAS 16')		031-037526
Control Tab	(THEATER BRASS 16')		031-037527
Tubular Clip			013-028002
Shaft			020-037238
Mounting Bracket			035-024205
Lever Mounting Bracket			035-024335

Cancel Linkage Assembly			060-037190
Wire Guide			045-030169
Over Center Spring (Toggel Spring)			012-038938
Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw (4 Used)			821-040314
Sems Round Head Machine Screw (Wire Guide Mounting)			821-040714
Keps Hex Nut			999-001258

PRESET SWITCH ASSEMBLY (LOWER) 008-027643

Switch Panel & Bracket Assembly (Drawbars, Flute & Strings 8', Tibias 8', Ensemble 8')			008-027674
Control Tab	(DRAWBARS)		031-037530
Control Tab	(FLUTE & STRING 8')		031-037531
Control Tab	(TIBIAS 8')		031-037532
Control Tab	(ENSEMBLE 8')		031-037533
Tubular Clip			013-028002
Shaft			020-037238
Mounting Bracket			036-024205
Lever Mounting Bracket			035-024335
Wire Guide			045-030169
Cancel Linkage Assembly			060-037190
Sems Round Head Machine Screw (For Wire Guide)			821-040714
Keps Hex Nut (For Wire Guide)			999-001258
Over Center Spring			012-038938

VIBRATO SWITCH ASSEMBLY 008-027645

Switch Panel & Bracket Assembly (On Upper)			008-027670
Switch Panel & Bracket Assembly (On Lower)			008-034547
Control Tab	(ON UPPER)		031-037528
Control Tab	(ON LOWER)		031-037529
Tubular Clip			013-028002
Shaft			020-037240
Mounting Bracket			035-024205
Lever Mounting Bracket			035-024335
Over Center Spring (Toggel Spring)			012-038938
Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw			821-040314
Spacer			044-018790
Reinforcing Strap			041-030605
Sems Round Head Machine Screw (For Strap)			821-030714
Keps Hex Nut		(For Strap)	999-001258
Resistor	390K	R420	600-021111
Resistor	220K	R409, R410	600-021051
Capacitor	.039mfd	C401, C402	413-010332

VIBRATO VARIATIONS SWITCH ASSEMBLY 008-027647

Switch Panel & Bracket Assembly		Vibrato Celeste I, Vibrato Celeste II	008-027679
Switch Panel & Bracket Assembly		(Vibrato Small)	008-027676
Switch Panel & Bracket Assembly		(Vibrato Chorus)	008-027677
Control Tab	(VIBRATO SMALL)		031-037544
Control Tab	(VIBRATO CHORUS)		031-037545
Control Tab	(VIBRATO CELESTE I)		031-037546
Control Tab	(VIBRATO CELESTE II)		031-037547
Tubular Clip			013-028002
Shaft			020-037238
Over Center Spring (Toggel Spring)			012-038938
Mounting Bracket			035-024205

Lever Mounting Bracket			035-024335
Cancel Lever Assembly			060-037188
Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw			821-040314
Washer	(Cancel Lever Mounting)		999-000016
Resistor	12K	R403	600-020751
Resistor	15K	R407, R408	600-020771
Resistor	18K	R404	600-020791
Resistor	39K	R405	600-020871
Resistor	8.2K	R406	600-020711

REVERB & VOLUME SOFT SWITCH ASSEMBLY 008-027642

Switch Panel & Bracket Assembly	(Reverb II)	008-027672
Switch Panel & Bracket Assembly	(Volume Soft)	008-027670
Switch Panel & Bracket Assembly	(Reverb I)	008-027673
Control Tab	(STEREO REVERB I)	031-037548
Control Tab	(STEREO REVERB II)	031-037549
Control Tab	(VOLUME SOFT)	031-037550
Tubular Clip		013-028002
Shaft		020-037238
Mounting Bracket		035-024205
Lever Mounting Bracket		035-024335
Over Center Spring (Toggel Spring)		012-038938
Flat Head Machine Screw		839-040214
Sems Round Head Machine Screw		821-040314
Resistor	56K	600-020911
Resistor	15Ω	600-020051
Resistor	10K	600-020731

MANUAL STOP SWITCH ASSEMBLY (LEFT HAND) 120-000019

MANUAL STOP SWITCH ASSEMBLY (RIGHT HAND) 120-000018

Mounting Block Assembly	(Left Hand)	063-037338
Mounting Block Assembly	(Right Hand)	063-037339
Contact Spring Assembly		012-027488
Clamp Spring		012-027613
Drawbar Stop		025-040198
#2 Bind Head Machine Screw (Drawbar Stop)		846-010414
Stop Slide		028-040899
Stop Channel		025-027829
#4-24x3/8" Round Head Tap Screw (Drawbar Knob Mounting)		901-030514
Stamped Stop Knob	(Brown 16')	031-034331
Stamped Stop Knob	(Black 16')	031-034332
Stamped Stop Knob	(Ivory 8')	031-034333
Stamped Stop Knob	(Brown 8')	031-034334
Stamped Stop Knob	(Black 8')	031-034335
Stamped Stop Knob	(Brown 5-1/3')	031-034337
Stamped Stop Knob	(Ivory 4')	031-034338
Stamped Stop Knob	(Black 2-2/3')	031-034339
Stamped Stop Knob	(Ivory 2')	031-034340
Stamped Stop Knob	(Black 1-3/5')	031-034341
Stamped Stop Knob	(Black 1-1/3')	031-034342

PEDAL STOP SWITCH ASSEMBLY 125-000026

Pedal Drawbar Assembly	(Left Hand)	060-036595
Stop Slide Assembly	(Left Hand)	060-036598

Stop Channel			025-027829
Stamped Stop Knob (Brown 16')			031-034331
#4-24x3/8" Round Head Tap Screw			901-030414
Pedal Drawbar Assembly (Right Hand)			060-036596
Stop Slide Assembly	(Right Hand)		060-036599
Stop Channel			025-027829
Stamped Stop Knob (Brown 8')			031-034334
#4-24x3/8" Round Head Tap Screw			901-030414
Cover Plate Assembly			060-027493
Mounting Block			025-027536
Plastic Gear			018-027663
Potentiometer	100K	(Left Hand)	676-000215
Potentiometer	100K	(Right Hand)	676-000216
Bracket (For Mounting Potentiometers)			035-027662
#3/8-32 Hex. Nut (For Mounting Potentiometer)			999-001199
#4 Stop Washer			045-027608
#4-24x3/8" Round Head Tap Screw (For Stop Washer)			901-030514
#4-40x3/16" Socket Set Screw (For Plastic Gear)			999-002003
Matching Transformer Assembly (Manual)			003-027486
Matching Transformer Assembly (Percussion)			003-027487
Terminal Strip Assembly			006-033265
Mounting Bracket			035-027563
Hex. Head Tapping Screw (Transformer Mounting)			924-050414

PERCUSSION & REITERATION DRIVER ASSEMBLY (E 100) 063-037568

Chassis Pan Assembly			009-028219
Percussion Driver Cable Assembly			011-028724
Transformer Assembly	T201		003-037287
Concentric Potentiometer	100K	R216, R208	676-000266
Transistor	Q201, Q202		001-021133
Diode	D201, D202		001-026010
Resistor	100K	R201, R202, R203, R204	600-020971
Resistor	33K	R205	600-020851
Resistor	10K	R206	600-020731
Resistor	18K	R207, R214	600-020791
Resistor	3.3K	R217	600-020611
Resistor	6.8K	R215	600-020691
Capacitor	10000pf	C201	425-010752
Capacitor	3900pf	C202	425-010642
Capacitor	1mfd	C203	407-060119
Capacitor	1mfd	C204	406-010292
Capacitor	4700pf	C206	425-010663
Shake Proof Lockwasher			999-000848
Hex Nut			999-001208
Knob			031-025911
Line Switch			008-034796
Shim (For Line Switch)			033-043006
Lampholder Assembly			016-034442
Pilot Light Lens			016-031454
Felt Washer			042-020820
Push-On Clip			013-031468
Lamp	6.3V		016-022885
Plastic Cap	(Lamp Hood)		025-024963
Truss Head Machine Screw (Painted-Black)			845-070318
Washer	(For Truss Head Machine Screw)		999-000061
Hex Washer Head Tapping Screw (Drawbar Mounting-Short)			927-030514
Hex Washer Head Tapping Screw (Drawbar Mounting-Long)			826-041714
Shielded Lead Assembly		(Percussion)	011-034775

Shielded Lead Assembly		(Volume Soft)	011-034774
Shielded Lead Assembly		(Reverberation)	011-037819
Shielded Lead Assembly		(Vibrato)	011-037820
Output Cable	(Lower Manual)		011-037830
Output Cable	(Upper Manual)		011-028667
Plastic Tie			013-031744
Felt (Adhesive Backed)			042-033312

CONTROL PANEL ASSEMBLY (E 200) 120-000016

Control Panel Assembly (Left Hand)			061-027633
Control Panel Assembly (Center)			061-027634

PERCUSSION SWITCH ASSEMBLY 008-028646

Switch Panel & Bracket Assembly (Chimes Solo)			008-027668
Switch Panel & Bracket Assembly (Add Vibrato)			008-027670
Switch Panel & Bracket Assembly (Harp Sustain Solo)			008-030044
Control Tab	(Chimes Solo)		031-037557
Control Tab	(Harp Sustain Solo)		031-037558
Control Tab	(Add Vibrato)		031-037561
Tubular Clip			013-028002
Shaft			020-037238
Mounting Bracket			035-024205
Lever Mounting Bracket			035-024335
Over Center Spring (Toggel Spring)			012-038938
Cancel Lever Assembly			060-025873
Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw			821-040314
Resistor	33K	R412, R413	600-020851

PRESET SWITCH ASSEMBLY (SWELL MANUAL) 008-028647

Switch Panel & Bracket Assembly (Drawbars, Flute Chorus 8', Swell Reeds 8', Full Swell 16')			008-027674
Control Tab	(DRAWBARS)		031-037530
Control Tab	(FLUTE CHORUS 8')		031-037551
Control Tab	(SWELL REEDS 8')		031-037552
Control Tab	(FULL SWELL 16')		031-037553
Tubular Clip			013-028002
Shaft			020-037238
Mounting Bracket			035-024205
Lever Mounting Bracket			035-024335
Over Center Spring (Toggel Spring)			012-038938
Cancel Linkage Assembly			060-037190
Wire Guide			045-030169
Sems Round Head Machine Screw (Wire Guide Mounting)			821-040714
Keps Hex Nut (Wire Guide Mounting)			999-001258
Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw			821-040314

VIBRATO SWITCH ASSEMBLY 008-028648

Switch Panel & Bracket Assembly (On Swell)			008-027670
Switch Panel & Bracket Assembly (On Great)			008-034547
Control Tab	(ON SWELL)		031-037559
Control Tab	(ON GREAT)		031-037560
Tubular Clip			013-028002
Shaft			020-037240
Mounting Bracket			035-024205
Lever Mounting Bracket			035-024335
Over Center Spring (Toggel Spring)			012-038938

Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw			821-040314
Strap-Reinforcing			041-030605
Spacer (Strap Mounting)			044-018790
Sems Round Head Machine Screw (Strap Mounting)			821-040714
Keps Hex Nut (Strap Mounting)			999-001258
Resistor	390K	R420	600-021111
Resistor	220K	R409, R410	600-021051
Capacitor	.039mfd	C401, C402	413-010332

PRESET SWITCH ASSEMBLY (GREAT) 008-028649

Switch Panel & Bracket Assembly (Drawbars, Diapason 8', Principal Chorus 8', Full Great 16')		008-027667
Control Tab	(DRAWBARS)	031-037530
Control Tab	(DIAPASON 8')	031-037554
Control Tab	(PRINCIPAL CHORUS 8')	031-037555
Control Tab	(FULL GREAT 16')	031-037556
Tubular Clip		013-028002
Shaft		020-037238
Mounting Bracket		035-024205
Lever Mounting Bracket		035-024335
Over Center Spring (Toggel Spring)		012-038938
Cancel Linkage Assembly		060-037190
Wire Guide		045-030169
Sems Round Head Machine Screw (Wire Guide Mounting)		821-040714
Keps Hex Nut	(Wire Guide Mounting)	999-001258
Washer	(Wire Guide Mounting)	999-000016
Flat Head Machine Screw		839-040214
Sems Round Head Machine Screw		821-040314
Output Cable	(Upper Manual–E200)	011-030303
Output Cable	(Lower Manual–E200)	011-030302
Matching Transformer & Bracket Assembly	(Lower Manual–E200)	003-037328

PERCUSSION & REITERATE DRIVER (E 200) 063-037567

CONTROL PANEL ASSEMBLY (E 300) 120-000027

Control Panel Assembly	(Left Hand)	061-030419
Control Panel Assembly	(Center)	061-040644
Control Panel Assembly	(Right Hand)	061-027632

PERCUSSION SWITCH ASSEMBLY #1 008-030512

Switch Panel & Bracket Assembly	(Chimes, Guitar)	008-027668
Switch Panel & Bracket Assembly	(Celesta)	008-027678
Switch Panel & Bracket Assembly	(Marimba)	008-030044
Control Tab	(CHIMES)	031-037534
Control Tab	(GUITAR)	031-037535
Control Tab	(MARIMBA)	031-037536
Control Tab	(CELESTA)	031-037562
Tubular Clip		013-028002
Shaft		020-037239
Mounting Bracket		035-024351
Lever Mounting Bracket		035-024335
Over Center Spring (Toggel Spring)		012-038938
Flat Head Machine Screw		839-040214
Sems Round Head Machine Screw		821-040314
Tie Strip		041-027176
Resistor	330K R411	600-021091

PERCUSSION SWITCH ASSEMBLY #2			008-030513
Switch Panel & Bracket Assembly	(Banjo)		008-027668
Switch Panel & Bracket Assembly	(Add Vibrato)		008-027670
Switch Panel & Bracket Assembly	(Reiterate)		008-027679
Switch Panel & Bracket Assembly	(Xylophone)		008-030044
Control Tab	(XYLOPHONE)		031-037537
Control Tab	(BANJO)		031-037538
Control Tab	(REITERATE)		031-037539
Control Tab	(ADD VIBRATO)		037-037541
Tubular Clip			013-028002
Shaft			020-037239
Mounting Bracket			035-024351
Lever Mounting Bracket			031-035335
Over Center Spring			012-038938
Tie Strip			041-027176
Resistor	4.7Ω	R419	600-021561
Resistor	33K	R412, R413	600-020851
Resistor	220Ω	R420	600-020331
Flat Head Machine Screw			839-040214
Sems Round Head Machine Screw			821-040314
Matching Transformer & Bracket Assembly	(Manual)		003-037327
Matching Transformer & Bracket Assembly	(Percussion)		003-037495
PERCUSSION & REITERATION DRIVER ASSEMBLY (E 300)			063-037566
Potentiometer	100K	R208	676-000129
Knob			031-031757
MANUAL ASSEMBLY (UPPER–E100)			119-000020
Manual Frame Assembly			060-037336
Switch Cover Assembly			060-037333
Top Cover Assembly			060-027516
Key Comb Assembly	(12 Key)		057-037989
Key Comb Assembly	(13 Key)		057-037990
Screw	(Key Comb Mounting)		831-070314
Bracket & Channel Assembly		(Key - All Same)	060-033392
Sems Bind Head Machine Screw (Key Mounting)			850-000002
Natural Key	(Ivory–C)		025-042279
Natural Key	(Ivory–D)		025-042280
Natural Key	(Ivory–E)		025-042281
Natural Key	(Ivory–F)		025-042282
Natural Key	(Ivory–G)		025-042283
Natural Key	(Ivory–A)		025-042284
Natural Key	(Ivory–B)		025-042285
Natural Key	(Ivory–CX–Last Key On Manual)		025-042286
Sharp Key	(Black)		025-032672
Screw	(Top Cover Mounting - Front)		925-050314
Screw	(Top Cover Mounting - Rear)		831-070414
Screw	(Switch Cover Mounting - Bottom)		900-050334
Tapped Strip	(Inside Manual Frame To Hold Top Cover)		041-027519
MANUAL ASSEMBLY (LOWER–E100)			119-000018
Manual Frame Assembly			060-037336
Switch Cover Assembly			060-037334
MANUAL ASSEMBLY (UPPER–E200)			119-000019
Manual Frame Assembly			060-037337
Switch Cover Assembly			060-037333

MANUAL ASSEMBLY (LOWER–E200)			119-000021
Manual Frame Assembly			060-037336
Switch Cover Assembly			060-037334
MANUAL ASSEMBLY (UPPER–E300)			119-000031
Manual Frame Assembly			060-038761
Switch Cover Assembly			060-037633
MANUAL ASSEMBLY (LOWER–E300)			119-000030
Manual Frame Assembly			060-037337
Switch Cover Assembly			060-037334
Front Strip	(E 100-E 300)		061-038921
Front Strip	(E 200)		061-038920
Vibrato Line Assembly	(E 100, E 200)		121-000084
Vibrato Line Assembly	(E 300)		121-000053
Cable Assembly	(Generator To Manuals)		011-025633
Sustain Keyer Cable	(E 100)		011-037828
Sustain Keyer Cable	(E 200)		011-037829
Lower Manual Mounting Bracket (No Felt–Left Hand)			035-030685
Upper Manual Mounting Bracket (No Felt–Left Hand)			035-030686
Upper Center Bracket & Felt Assembly			060-030691
Lower Center Bracket & Felt Assembly			060-030692
Upper Bracket & Felt Assembly	(Right Hand)		060-030687
Lower Bracket & Felt Assembly	(Right Hand)		060-030688
End Block	(Left Hand - 2 Used) Textured		025-043984
End Block	(Right Hand - 2 Used) Textured		025-035707
Screw	(End Block)		831-100914
Screw	(Control Panel To Manual)		831-080414
Screw	(Front Strip)		938-050333
GENERATOR & MOTOR ASSEMBLY	**117V**	**60Hz**	112-000025
GENERATOR & MOTOR ASSEMBLY	**117V**	**50Hz**	112-000026
GENERATOR & MOTOR ASSEMBLY	**220V**	**60Hz**	112-000027
GENERATOR & MOTOR ASSEMBLY	**220V**	**50Hz**	112-000028
SYNCHRONOUS MOTOR	115V	60Hz	021-033801
SYNCHRONOUS MOTOR	115V	50Hz	021-033802
SYNCHRONOUS MOTOR	230V	60Hz	021-033803
SYNCHRONOUS MOTOR	230V	50Hz	021-033804
Motor Mounting Bracket			035-027354
Motor Clamp			013-024427
Motor Capacitor	115V	60Hz (Use with Shunt Wound Motor Only)	499-033806
Motor Capacitor	115V	50/60Hz	499-033807
Motor Capacitor	230V	50/60Hz	499-033805
Capacitor Clamp			013-024313
Oval End Cap (Motor Capacitor)			041-024838
GENERATOR ASSEMBLY	60Hz		113-000013
GENERATOR ASSEMBLY	50Hz		113-000014
Generator Cover Assembly			115-000001

Cover Felt (Generator)			042-030359
Terminal Panel Assembly		(AC)	006-024326
Terminal Strip Assembly		(AC)	006-024265
Insulator Strip		(AC)	036-024328
Post		(AC)	044-031434
Terminal Cover		(AC)	041-022076
Motor Coupler			017-024242
Motor Coupling Spring			012-029132

VIBRATO SCANNER–ASSEMBLIES

Vibrato Scanner Assembly		60Hz	121-000078
Vibrato Scanner Assembly		50Hz	121-000079
Felt Washer (Scanner Mounting)			042-020820
Drive Gear Coupling Spring (Scanner)			012-041463

PEDAL SWITCH ASSEMBLY 116-000013

Switch Frame Assembly			008-030126
Switch Assembly			008-030134
Cable Assembly			011-030118
Plastic Clamp			013-031727
Resistor	100Ω	(21 Used)	600-020251
Resistor	47K	R641, R642, R643	600-020891
Resistor	390Ω	R644	600-020391
Capacitor	.3mfd	C643	406-010212
Capacitor	.39mfd	C642	406-010222
Capacitor	.68mfd	C641	406-010282
Felt (Down Stop)			042-030119
Switch Cover			041-030105

SWELL PEDAL ASSEMBLIES

Swell Pedal Assembly (E 100)			123-000013
Swell Pedal Assembly (E 200)			123-000015
Swell Pedal Assembly (E 300)			123-000014
Pedal Assembly	(E 100, E 300)		123-000022
Pedal Assembly	(E 200)		060-033288
Shutter Assembly			060-033749
Light Bulb Socket Assembly			040-033419
Photocell Housing Base Assembly			040-033600
Photocell Housing Cover			025-032880
Photoelectric Cell Adapter			025-030102
Photoconductive Cell		(E 100)	040-031873
Photoconductive Cell		(E 200, E 300)	040-031872
Diffuser			016-030153
Light Bulb			016-031748

HARP SUSTAIN KEYER ASSEMBLY (E 100) 124-000052

Printed Wiring Board Assembly		Frequencies 25 thru 46-E 200, Frequencies 37 thru 58-E 100	124-000046
Printed Wiring Board Assembly			023-039576
Resistor	47K	R502	600-220891
Resistor	1000Ω	R504	600-220491
Resistor	2200Ω	R501	600-220571
Transistor	Q501		001-021133
Capacitor	15mfd	C502 (22 Used)	407-050169
Printed Wiring Board Assembly		Frequencies 46 thru 73, Frequencies 58 thru 85	124-000047
Capacitor	15mfd	C502 (11 Used)	407-050169
Capacitor	8mfd	C502 (11 Used)	407-060129

HARP SUSTAIN KEYER & PREAMPLIFIER 124-000050

Printed Wiring Board Assembly				023-039579
Resistor	330Ω	R525		600-020371
Resistor	680Ω	R541		600-020451
Resistor	1000Ω	R504		600-020491
Resistor	1500Ω	R529, R513–E 100		600-020531
Resistor	1200Ω	R516–E 200		600-020511
Resistor	2200Ω	R501		600-020571
Resistor	4700Ω	R521, R516–E 100		600-020651
Resistor	6800Ω	R511, R512, R513		600-020691
Resistor	10K	R526, R503		600-020731
Resistor	68K	R524		600-020931
Resistor	39K	R515		600-020871
Resistor	47K	R502		600-020891
Resistor	150K	R523, R528		600-021011
Resistor	220K	R527		600-021051
Resistor	470K	R522		600-021131
Resistor	33Ω	R518		600-020132
Resistor	2700Ω	R517, R540		600-020592
Resistor	180K	R531		600-021031
Resistor	5600K	R513–E 200		600-020671
Capacitor	.068mfd	C521–E 100		407-010121
Capacitor	.1mfd	C513		407-010142
Capacitor	100mfd	Electrolytic Miniature	C523	407-010029
Capacitor	2mfd	Electrolytic Miniature	C522	407-060109
Capacitor	8mfd	Electrolytic Miniature	C502–E 100	407-060129
Capacitor	15mfd	Electrolytic Miniature	C501	407-050169
Capacitor	.01mfd	C511		413-110072
Capacitor	.1mfd	C524		413-110142
Capacitor	3900pf	C512		425-010642
Capacitor	.033mfd	C525–E 200		406-010102
Capacitor	.03mfd	C512–E 200		413-110192
Capacitor	.02mfd	C525–E 100		406-010182
Transistor	Q501			001-021133
Trimmer Potentiometer		20K	R530	676-000015

HARP SUSTAIN KEYER ASSEMBLY (E 200) 124-000053

REVERBERATION UNIT 121-000008

SPEAKERS

Speaker 15"	(E100, E200, E300)	014-023421
Speaker 8"	(E100, E200, E300)	014-024398
Speaker 8"	(E100)	014-028077
Speaker 8"	(E200, E300)	014-028078

PEDAL DIVIDER ASSEMBLY 124-000051

Printed Wiring Board & Terminal Assembly			023-038494
Resistor	100Ω	R703	600-020251
Resistor	820Ω	R717	600-020471
Resistor	1500Ω	R721	600-020531
Resistor	4700Ω	R702	600-020651
Resistor	10K	R700, R708	600-020731
Resistor	15K	R706, R708	600-020771
Resistor	27K	R720	600-020831
Resistor	33K	R707	600-020851
Resistor	47K	R704, R709, R710, R711	600-020891

Resistor	120K	R712		600-020991
Resistor	100K	R719		600-020971
Resistor	180K	R715		600-021031
Resistor	270K	R701		600-021071
Resistor	390K	R714		600-021111
Resistor	680K	R705		600-021171
Resistor	150K	R713		600-021011
Trimmer Potentiometer		250K	R716	676-000027
Capacitor Electrolytic Miniature		50mfd	C714	407-030089
Capacitor Electrolytic Miniature		1mfd	C715, C702, C703	407-060119
Capacitor Electrolytic Miniature		80mfd	C716	407-060259
Capacitor	.0068mfd	C713		425-010702
Capacitor	.027mfd	C708, C710		413-110092
Capacitor	.047mfd	C704, C711		413-110112
Capacitor	.1mfd	C706, C707		413-110142
Capacitor	.22mfd	C705		413-110162
Capacitor	.03mfd	C717		413-110192
Capacitor	.01mfd	C712		413-110072
Transistor	Q701, Q702, Q703, Q704, Q705, Q706			001-021133
Diode	D702			001-026010
Printed Divider Network (Couplate)				058-028540

PREAMPLIFIER ASSEMBLY 117-000012

Chassis Pan Assembly				009-027485
Percussion Board & Component Assembly				063-028703
Terminal Board & Lug Assembly				006-027489
Resistor	560Ω	R130		600-020431
Resistor	4700Ω	R162		600-020651
Resistor	10K	R143, R145		600-020731
Resistor	100K	R149, R152, R160		600-020971
Resistor	47K	R151		600-020891
Resistor	27K	R140, R141		600-020831
Resistor	68K	R142, R157		600-020931
Resistor	150K	R150		600-021011
Resistor	68K	R153, R155		607-020014
Resistor	1.5Meg	R139		600-021251
Resistor	470K	R129, R159		600-021131
Resistor	2.7Meg	R132		600-021311
Resistor	220K	1Watt	R146	600-031051
Resistor	10K	R131		600-040731
Capacitor	100mfd	10V	C116	407-030059
Capacitor	500mfd	25V	C128	407-070159
Capacitor	1mfd	200V	C117	421-021113
Capacitor	2700pf	500V	C122	425-010601
Capacitor	1500pf	400V	C125	425-010542
Preamplifier Board & Component Assembly				063-028702
Terminal Board & Lug Assembly				006-027499
Resistor	1500Ω	R114		600-020531
Resistor	2200Ω	R103, 124		600-020531
Resistor	6800Ω	R118		600-020691
Resistor	18K	R117		600-020791
Resistor	47K	R102, 116, 123		600-020891
Resistor	220K	R106, 107, 109, 110, 111, 127, 128, 137		600-021051
Resistor	270K	R112		600-021071
Resistor	470K	R101,122		600-021131
Resistor	1.0Meg	R105, 115, 126		600-021211
Resistor	2.2Meg	R104, 119, 125		600-021291
Resistor	68K	R113		600-020931

Capacitor	.22mfd	100V	C108	406-010162
Capacitor	100mfd	3V	C104, 106, 114	407-010029
Capacitor	.25mfd	200V	C103, 113	421-021063
Capacitor	.02mfd	400V	C120	422-032012
Capacitor	.047mfd	400V	C107	422-032022
Capacitor	82pf	500V	C102, 112	425-010232
Capacitor	.1mfd	400V	C100, 110	422-032032
Capacitor	.02mfd	500V	C105, 115	425-010763
Plug Assembly	(P110 - 9 Pin)			011-028733
Plug Assembly	(P102 - 3 Pin)			011-037691
Plug Assembly	(P105 - 3 Pin)			011-037698
Tubes EF86/6267	V101			002-006503
Tubes 12AX7	V106			002-012301
Tubes 12AU7	V104			002-012300
Tubes 12AX7	V105 (Noise Null)			002-000001
Tube Shield				010-041481
Potentiometer	100K	R142	(Noise Null A)	676-000105
Potentiometer	10K	R147, 154	(Noise Null B, Percussion Cut Off)	676-000143
Potentiometer	150K	R108	(Vibrato Balance)	676-000152
Potentiometer	1Meg	R159	(Percussion Level)	676-000104
Resistor	820Ω	R144		600-020471
Resistor	1200Ω	R158		600-020511
Resistor	3900Ω	R134		600-020631
Resistor	4700Ω	R165		600-020651
Resistor	10K	R148, 164		600-020731
Resistor	100K	R160		600-020971
Resistor	2.7Meg	R136		600-021311
Resistor	10Meg	R135		600-021451
Resistor	500Ω 5W	R163		626-060291
Resistor	40K 3W	R161		602-050171
Resistor	33K	R151 Select One, if Needed		600-020851
Resistor	47K	R151 Select One, if Needed		600-020891
Resistor	100K	R151 Select One, if Needed		600-020971
Capacitor	100mfd	3V	C118	407-010029
Capacitor	27pf	500V	C101	425-010112
Capacitor	100pf	500V	C119	425-010842
Capacitor	Electrolytic	100-80-20mfd/300V	C127A, 127B, 127C	450-030102
Washer	(Percussion & Preamplifier Board Mounting)			999-000050
Screw (Used with Washer 999-000050)				831-070414

POWER AMPLIFIERS

Power Amplifier	120V	60Hz	126-000028
Power Amplifier	120V	50Hz	126-000029
Power Amplifier	234V	50-60Hz	126-000030
Chassis Pan Assembly			009-028790
Plug Assembly	(12 Pin White)		005-031785
Plug Assembly	(3 Pin White)		005-039157
Plug Assembly	(3 Pin Red)		005-039159
Female Pin	For #18 Wire		007-031798
Female Pin	For #22 Wire		007-031797
Power Transformer	120V	60Hz	003-028788
Power Transformer	120V	50Hz	003-037858
Power Transformer	234V	50-60Hz	003-037859
Filter Choke Assembly			003-025859
Output Transformer	(Reverberation Output)		003-036552
Output Transformer	(Audio Output)		003-030072
Potentiometer	50K (Reverb Level)		676-000103
Potentiometer	10K (Bias Balance)		676-000143

Potentiometer	500K (Organ Level)						676-000152
Resistor	820Ω						600-020471
Resistor	1000Ω						600-020491
Resistor	1200Ω						600-020511
Resistor	1500Ω						600-020531
Resistor	2200Ω						600-020571
Resistor	2700Ω						600-020591
Resistor	4700Ω						600-020651
Resistor	10K						600-020731
Resistor	15K						600-020771
Resistor	47K						600-020891
Resistor	3900Ω						600-020631
Resistor	56K						600-020911
Resistor	33K						600-020851
Resistor	100K						600-020971
Resistor	3300Ω						600-020611
Resistor	220K						600-021051
Resistor	82K						600-020951
Resistor	5600Ω						600-020671
Resistor	470K						600-021131
Resistor	1Meg						600-021211
Resistor	3.3Meg						600-021331
Resistor	4.7Ω	5%					600-020172
Resistor	1500Ω	5%					600-020292
Resistor	1800Ω						600-020551
Resistor	470Ω						600-020411
Resistor	4700Ω	1W					600-030651
Resistor	10K	1W					600-030731
Resistor	300Ω	1W	5%				600-030362
Resistor	1800Ω	1W	10%				600-030551
Resistor	10Ω		1%				625-020753
Resistor	64Ω	10W					604-070071
Resistor	800Ω	10W					604-070401
Resistor	1000Ω	10W					604-070441
Capacitor	100mfd	3V					407-010029
Capacitor	100mfd	10V					407-030059
Capacitor	100mfd	50V					407-080069
Capacitor	.047mfd	400V					422-032022
Capacitor	.1mfd	400V					422-032032
Capacitor	.47mfd	100V					406-010302
Capacitor	.027mfd	600V					417-040042
Capacitor	100pf						425-010252
Capacitor	220pf						425-010332
Capacitor	680pf						425-010462
Capacitor	1000pf						425-010502
Capacitor	1200pf						425-010522
Capacitor	3300pf						425-010622
Capacitor	4700pf						425-010662
Capacitor	.01mfd						425-010752
Capacitor	.02mfd						425-010763
Capacitor	2200pf						425-030583
Capacitor	.018mfd						413-010302
Capacitor Electrolytic		50/50mfd	150V				450-040401
Capacitor Electrolytic		30/30/30/20mfd					450-040301
Capacitor Electrolytic		100mfd	25V				450-040084
Capacitor Electrolytic		20mfd	350V				450-040087
Capacitor Electrolytic		40mfd	400V	–	40mfd	500V	450-040095
Capacitor Electrolytic		500/500/500mfd					450-030103

Choke				003-030753
Miniature Lamp				016-030445
Tube	7591			002-006704
Tube	7247			002-006307
Tube	12AU7A			002-012300
Tube	6GW8/ECL86			002-006401
Tube	5AR4/GZ-34			002-005200
Tube	6CA4/EZ81			002-006200
Tube Shield				010-041481
Zener Diode				001-023031
Diode				001-024052
Strain Rel ef				013-035998
Cord & Plug Assembly (A.C)				011-033233
Potentiometer (Hum Balance)				676-000301

CLICK FILTER ASSEMBLY 063-030225

Printed Wiring Board & Terminal Assembly				023-030227
Tuning Coil Assembly				003-033603
Resistor	180K			600-021031
Resistor	10K			600-020731
Resistor	82K			600-020951
Capacitor	.001mfd			425-010502
Capacitor	.0033mfd			425-010622
Capacitor	.0022mfd			425-010582

BRUSH & CYMBAL BOARD ASSEMBLY 124-000020

Printed Wiring Board				023-032934
Pin Connector				007-028499
Resistor	47Ω	R905, 916		600-020171
Resistor	390Ω	R920		600-020391
Resistor	10K	R906, 918		600-020731
Resistor	100K	R902, 909		600-020971
Resistor	220K	R911		600-021051
Resistor	1Meg	R901, 910, 912, 914		600-021211
Resistor	2.2Meg	R908		600-021291
Resistor	3.3Meg	R904		600-021331
Resistor	3.9Meg	R903		600-021351
Resistor	5.6Meg	R915		600-021391
Resistor	150Ω	R919		600-020291
Resistor	6 8Meg	R921		600-021411
Capacitor	.01mfd	100V	C901, 904, 906, 907, 908, 911, 912, 914	413-110072
Capacitor	.1mfd	100V	C910	413-110142
Capacitor	.33mfd	100V	C909	413-110172
Capacitor	.05mfd	100V	C902	413-110212
Capacitor	.00068mfd		C903	426-010462
Capacitor	.0047mfd		C905	426-010663
Capacitor	80mfd	25V	C913	407-060259
Potentiometer	50K	R906, 917		676-000019
Potentiometer	250K	R913		676-000027
Potentiometer	20K	R922		676-000015
Coil Assembly		L901, 902		003-030753
Filter Choke Assembly		L903		003-027183
Diode		D901, 902, 904, 905		001-026010
Transistor		Q901		001-021133
Transistor		Q902, 905, 906		001-021134
Transistor		Q903		001-021135
Noise Transistor		Q904 (Clip Collector Lead)		001-021211

MUSIC LIGHT ASSEMBLY (E 262)

Lamp Socket Assembly (L.H.)			004-038701
Lamp Socket Assembly (R.H.)			004-038702
Wire & Connector Assembly			011-038739
Wire & Connector Assembly			011-038740
Slide Switch Assembly			008-032561
Light Shield			041-030394
Bracket (R.H.)			035-039755
Bracket (L.H.)			035-039756
Switch Cover			041-030580
Flourescent Lamp			016-030407
Light Diffuser			016-030461
Starter			063-030408
Starter Socket			004-030409
Base Plate (Starter Socket)			041-030420
Starter Box Cover			041-039759
Capacitor	.02mfd	C604	425-010763
Shield			010-039750
Heat Shield (Ballast)			010-030439
Felt Spacer (Roll Top Groove At Rear)			042-038566
Pin Housing (6 Pin-Female)			005-039083
Socket Housing (6 Pin-Male)			005-039092
Grommet			043-020675

WOODWORK

Cabinet Assembly E111 (Red Mahogany)	111-000039
Case Assembly	050-000160
Top Panel & Music Rack Assembly	050-000175
Music Rack Assembly	050-000611
Cabinet Assembly E112, 312 (Light Walnut)	111-000040
Case Assembly	050-000161
Top Panel & Music Rack Assembly	050-000176
Music Rack Assembly	050-000612
Cabinet Assembly E133, 333 (Dark Cherry)	111-000041
Case Assembly	050-000162
Top Panel & Music Rack Assembly	050-000177
Music Rack Assembly	050-000613
Cabinet Assembly E143, 343 (Medium Cherry)	111-000042
Case Assembly	050-000163
Top Panel & Music Rack Assembly	050-000178
Music Rack Assembly	050-000613
Cabinet Assembly E182, 382 (Sherry Walnut)	111-000043
Case Assembly	050-000164
Top Panel & Music Rack Assembly	050-000179
Music Rack Assembly	050-000614
Cabinet Assembly E262 (Light Walnut)	111-000044
Case Assembly	050-000165
Top Panel & Music Rack Assembly	050-000180
Music Rack Assembly	050-000172
Cabinet Assembly E265 (Chapel Oak)	111-000045
Case Assembly	050-000166
Top Panel & Music Rack Assembly	050-000181
Music Rack Assembly	050-000173
Cabinet Assembly E311 (Red Mahogany)	111-000046
Case Assembly	050-000160
Top Panel & Music Rack Assembly	050-000175
Music Rack Assembly	050-000611

PEDAL KEYBOARD ASSEMBLIES

Pedal Keyboard Assembly (Packed) E112, 162, 262, 312	153-000003
Pedal Keyboard Assembly (Packed) E122, 333	153-000005
Pedal Keyboard Assembly (Packed) E111, 311	153-000007
Pedal Keyboard Assembly (Packed) E143, E343	153-000008
Pedal Keyboard Assembly (Packed) E182, 382	153-000010
Pedal Keyboard Assembly (Packed) E165, 265	153-000011

BENCH ASSEMBLIES

Bench Assembly (Packed) E111	152-000030
Bench Assembly (Packed) E112, 312	152-000031
Bench Assembly (Packed) E133, 333	152-000032
Bench Assembly (Packed) E143, 343	152-000033
Bench Assembly (Packed) E182, 382	152-000034
Bench Assembly (Packed) E162, 262	152-000035
Bench Assembly (Packed) E165, 265	152-000036
Bench Assembly (Packed) E311	152-000037

PANEL & GRILLE CLOTH ASSEMBLIES

Panel & Grille Cloth Assembly E111, 311	052-037358
Panel & Grille Cloth Assembly E112, 312	052-037357
Panel & Grille Cloth Assembly E133, 333	052-037359
Panel & Grille Cloth Assembly E143, 343	052-037360
Panel & Grille Cloth Assembly E182, 382	052-037361
Panel & Grille Cloth Assembly E262	052-037821
Panel & Grille Cloth Assembly E265	052-037822

MISCELLANEOUS

Shielded Lead Assembly (Reverb. Pickup)	200-010332
Shielded Lead Assembly (Reverb. Driver)	200-010335
Spacer (Click Filter)	044-026827
Fastener (Rear Cover-Twist Button)	013-040269
Lower Manual Cover	046-027474
Fuse Clip	013-036811
Drive Screw Nail (Fuse Clip)	999-003005
Edging (Bottom Of Grille Cloth)	055-023936
Bezel (Swell Pedal Housing Trim)	055-023331
Plastic Tie	013-031744
Power Supply Cable (Console)	011-028681
Capacitor 10mfd C601 (Crossover)	407-080269
Oil Tube Assembly (Generator Oil)	015-025581
Grommet (Generator Mounting)	043-024246
Teenut (Generator Mounting)	999-029366
Embossed Logo (Front Strip/Control Panel)	038-025935

H000-000468 9/80 5C

INSTALLATION AND MAINTENANCE INSTRUCTION

INSTALLATION INSTRUCTIONS

Connect only to power supply of voltage and frequency shown on name plate.

The generator in this organ is permanently mounted and requires no loosening of shipping bolts.

Place console at least 2 inches from wall for ventilation and for best acoustic results.

If organ has a tone cabinet, see card on cabinet for additional instructions.

OILING INSTRUCTIONS

Lubricate the tone generator and motor once a year according to instruction plate at rear of console. Use the chart at right as a reminder. Use only the oil supplied with the organ. When supply is exhausted, you may purchase additional oil from your dealer or direct from the factory.

MAINTENANCE

With the exception of regular oiling, the organ will require little attention. If it should need servicing, call your Hammond dealer or write to the factory.

IMPORTANT - Always supply model designation and serial number when writing.

CLEANING

Plastic Keys and Controls - Clean lightly with damp cloth or chamois; wiping with a dry cloth up an electrostatic charge that attracts dust. U soap and lukewarm water if necessary; dry withou sive rubbing. Do not use boiling water, strong such as alcohol, dry cleaning fluids, or window fluids which contain such solvents.

Woodwork - Dust with a soft, damp cloth or chamo necessary, dampen cloth lightly with a solution soap and lukewarm water. Remove solution, us cloth dampened with clean water. Dry thoroughly, with the grain. Use a good grade furniture wax or preferably liquid. Avoid use of paste waxes or polishes. Excessive rubbing in one spot or at e damage finish.

MOVING OR SHIPPING

Remove the pedals by raising slightly and slid back. If the organ has a tone cabinet, discon console-to-cabinet cable. See card on tone cabi

IMPORTANT - If the organ is to be shipped by other than a regular furniture mover, arrange w local Hammond dealer to have it properly packed.

PRINTED IN U.S.A.

HAMMOND ORGAN COMPANY

GRAPHICS COMMUNICATIONS

HAMMOND ORGAN COMPANY

4200 W. Diversey Avenue Chicago 39, Illinois, U.S.A.

PO-30194-0