



# Service Bulletin

06 February 2008

SWR Sound Corp.  
9130 Glenoaks Blvd.  
Sun Valley CA, 91352  
(818) 253-4797

## Installing the noise suppression circuit (PCBA 700075) in the SWR LA12 and LA15 Bass Guitar Amplifiers.

1. Disconnect the AC cord.
2. Remove all eight screws from the metal rear panel.
3. Flip panel so that wiring is toward you.
4. Disconnect harness connector J3. *See figure 1.*
5. Remove the Phillips head screw adjacent to J3 and discard it.
6. Install assembly number 700075 by placing pin 1 on "J3IN" over J3, pin1 on the amp PCB. Install spacer and screw (provided). *See figure 2.*
7. Place harness connector previously on J3 onto connector marked "J3OUT" *See figure 3.*
8. Disconnect harness (AC connector) J2. Insert terminated yellow wire onto J2, pin 2 – between the two red wires. *See figures 4.*
9. Re-install J2. *See figure 5.*
10. Use a small cable tie to prevent yellow wire from rattling.
11. Reverse steps 3, 2 and 1.

Please note: When unit is powered-up from now on, there will be no audio for the first 3-5 seconds.

