

# WARNING!!!!!!!!!!!!!!!!!!!!!!!!!!!!

QUALIFIED ELECTRONIC TECHNICIANS SHOULD PERFORM THIS ENHANCEMENT. PEAVEY ELECTRONICS WILL NOT BE RESPONSIBLE FOR EQUIPMENT DAMAGED AS A RESULT OF IMPROPER INSTALLATION OF THE PARTS. SHOULD YOU HAVE QUESTIONS REGARDING THIS INSTALLATION, PLEASE DO NOT HESITATE TO CONTACT OUR REPAIR ASSISTANCE DEPARTMENT AT THE FACTORY BY PHONING (601) 483-5365.

## PEAVEY PROFEX II MODIFICATION KIT

<u>FROM</u>	<u>TO</u>	<u>DESIGNATION</u>	<u>PV#</u>
4558IC	OPA2604	U903, U901, U902 U700	c57000092

**NOTE; MAKE SURE THAT THE YOU INSERT THE UC CHIPS CORRECTLY AND SEAT THEM PROPERLY IN THEIR SOCKETS. THERE IS A NOTCH AT THE END OF THE SOCKET AND AT THE END OF THE IC CHIP THAT WHOULD BE MATCHED WHEN REINSTALLING THE REPLACEMENT IC'S.**

1/17/2001

