

SPACERS ARE BETWEEN TUBE SOCKETS
AND PCB. NUTS ARE TO BE ON BOTTOM
(CIRCUIT) SIDE OF PC BOARD.
TYPICAL, 12 PLACES


FOR ASSEMBLY P/N: 07-365-01

USE SCHEMATIC # 07S365

NOTES:

1. APPLY RTV SILICONE SEALANT PER SLM DOCUMENT NUMBER 00A005-00

CAUTION:
THIS ASSEMBLY DRAWING IS PROVIDED FOR USE BY QUALIFIED PERSONNEL.
TO AVOID RISK OF ELECTRIC SHOCK, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.
DO NOT PERFORM ANY SERVICING BEYOND THAT EXPLAINED IN THE OPERATING INSTRUCTIONS.

0	3/10/06	CONTROL ISSUE				
REV	Date	DESCRIPTION	Ecr(s)/Ecn(s)	Chgd By	Appvd by	Date
THE INFORMATION CONTAINED ON THIS DRAWING IS PROPRIETARY TO ST. LOUIS MUSIC, INC.						
Signatures:		Date:	 1901 Congressional, St. Louis, MO 63146			
Drawn:	REM	1/23/06				
Checked:						
Released:			First Used On:			
Plot Date:	Thu Apr 20, 2006	Drawing Size:	B	Drawing Title:		
Plot Time:	14:09:17	Drawing Type:	ASSEMBLY	PWA - TUBE BOARD		
Tolerance:		Class Code:	NONE	Drawing Number:		
		Sheet	1 of 1	07-365		