



C37 - Substitute with .001uF? or even 680pF or 820pF? (for more bass response?)

R56 replaced with 500kA pot. Would I be best connecting the cable shield for this pot to the same ground trace as the other side of R70? (It seems to pick up a bit of interference when ground to the amp chassis).