

- |                             |                                  |                       |
|-----------------------------|----------------------------------|-----------------------|
| 1 = SIGNAL INPUT (RED)      | 5 = SPEAKER OUT PLUS (VIO)       | 9 = 10VAC IN (BLU)    |
| 2 = SIGNAL SHIELD           | 6 = GROUND (GRN)                 | 10 = 10VAC IN (BLU)   |
| 3 = +50VDC IN (RED)         | 7 = -50VDC IN (BLK)              | 11 = -15VDC OUT (BLK) |
| 4 = SPEAKER OUT MINUS (WHT) | 8 = PREAMP 3 ENABLE IN (ORN/GRN) | 12 = +15VDC OUT (RED) |

