

HOW TO ORDER PARTS FOR YOUR SILVERTONE AMPLIFIER

These authorized replacement parts may be ordered through any Sears Retail Store or the Mail Order store which serves the territory in which you live. Prices upon application from Sears, Roebuck and Co. The parts are shipped prepaid.

When ordering parts always give:

1. The PART NUMBER (number printed on the part if different from that shown in this list) and the DESCRIPTION. When no number is assigned order by number and rating.
2. The CHASSIS and CATALOG NUMBERS. The chassis number will be found on a metal plate on the top of the chassis. This plate is pictured at right. The catalog number will be found on the control panel of the amplifier.



SEARS, ROEBUCK AND COMPANY

Parts List

<u>Schematic Location</u>	<u>Part No.</u>	<u>Name & Description</u>
R1, R2	H20004 P78	Resistor 22K 1/2 Watt
R3, R18, R19	H20004 P86	Resistor 100K 1/2 Watt
R4, R6	H20066 P59	Volume Control 500K #6 Taper
R5, R7	H20004 P94	Resistor 470K 1/2 Watt
R8	H20004 P63	Resistor 1200 1/2 Watt
R16, R20	H20004 P62	Resistor 1K 1/2 Watt
R9	H20004 P397	Resistor 24K 1/2 Watt
R10	H20004 P98	Resistor 1 Meg 1/2 Watt