

# Parts List

Schematic Location	Part No.	Name & Description
R1, R2	H20004 P78	Resistor 22K 1/2 Watt
R3, R18, R19	H20004 P86	Resistor 100K 1/2 Watt
R4, R6	H20066 P59	Volume Control 500K #6 Taper
R5, R7	H20004 P94	Resistor 470K 1/2 Watt
R8	H20004 P63	Resistor 1200 1/2 Watt
R16, R20	H20004 P62	Resistor 1K 1/2 Watt
R9	H20004 P397	Resistor 24K 1/2 Watt
R10	H20004 P98	Resistor 1 Meg 1/2 Watt
R11, R12, R22	H20004 P91	Resistor 270K 1/2 Watt
R13	H20066 P60	Tone Control 1 Meg #6 Taper w/switch
R14	H20004 P82	Resistor 47K 1/2 Watt
R15	H20004 P148	Resistor 36 1/2 Watt 5%
R17	H20004 P180	Resistor 7500 1/2 Watt 5%
R21	H20004 P213	Resistor 180K 1/2 Watt 5%
R23	H20012 P23	Resistor 200K 5 Watt
R24	H20004 P67	Resistor 2700 1/2 Watt
R25	H20013 P63	Resistor 25K 10 Watt
R26	H20004 P 404	Resistor 1.5 1/2 Watt
C1	H20048 P14	Capacitor 20-10/450, 50/25V.
C2	H20053 P5	Capacitor 10/25V.
C3	H20048 P8	Capacitor 20-20/450V.
C4	H20050 P80	Capacitor .05-600V.
C5	H20050 P55	Capacitor .01-600V.
C6	H20050 P15	Capacitor .002-600V.
C7	H20050 P10	Capacitor .001-600V.
C8, C9	H20050 P60	Capacitor .02-600V.
C10	H20050 P7	Capacitor .0001-500V. MICA
T1	H20166	Power Transformer
T2	H20201	Output Transformer
S1	H20034 P15	Octal Socket
S2, S3, S4, S5	H20034 P18	Octal Socket
S6	H20045 P21	Pilot Light Holder
J1, J2	H20207 P1	Phone Jack Open Type
J3	H20207 P2	Phone Jack Closed Type
	H20001 P9	Fuse Post, Ext. Type
F1	H20043 P1	Fuse 3 AG 2 Amp 250 V DC
	H20148 P8	Knob, Bar 1-1/4"
	H20189 P1	Strain Relief
	H20147 P1	Power Cord, SJ Type 7'
11	H20044 P14	Pilot Lamp #44
	H20118 P1	Shield (Tube)
	H20111 P15	Speaker, 12" PM, Alnico V, 3.2 ohms