

Capacitor	uF	Volts	Type	Desc
C01	10	25	Electrolytic	
C02	0.02	600	Poly	Coupling
C03	0.02	600	Poly	
C04	0.0022		Ceramic or Mica	2200pf Treble Ch2
C05	0.0022		Ceramic or Mica	2200pf Treble Ch2
C06	0.0022		Ceramic or Mica	2200pf Treble Ch1
C07	0.0022		Ceramic or Mica	2200pf Treble Ch1
C08	0.0015		Ceramic or Mica	1500pf Bass Ch2
C09	0.0015		Ceramic or Mica	1500pf Bass Ch1
C10	0.006		Ceramic or Mica	6000pf Bass Ch2
C11	0.006		Ceramic or Mica	6000pf Bass Ch1
C12	0.01	600	Poly	
C13	10	25	Electrolytic	
C14	0.01	600	Poly	
C15	0.01	600	Poly	
C16	0.01	600	Poly	
C17	0.01	600	Poly	
C18	0.01	600	Poly	
C19	0.01	600	Poly	
C20A	10	450	Compound Electrolytic	
C20B	10	450	Compound Electrolytic	
C21	10	450	Electrolytic	
C22	0.00068		Ceramic or Mica	680pf
C23	0.1	600	Poly	
C24	0.02	600	Foot switch	
C25	0.47	200	Paper-Oil	
C26	0.02	600	Poly	
C27	0.02	600	Poly	
C28	0.02	600	Poly	
C29	40	450	Electrolytic	
C30	16	450	Electrolytic	
C31	16	450	Electrolytic	
C32	0.05	600	Bipolar "death cap"	

Stage

Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, Tone Controls
Pre-amp, 6CG7 #1
Pre-amp, 6CG7 #1
Pre-amp, 6CG7 #1
Pre-amp, 12AX7 #2
Pre-amp, 12AX7 #2
Pre-amp, 6CG7 #2
Pre-amp, 6CG7 #2
Pre-amp, 6CG7 #2

Pre-amp, 6AU6 Tremolo
Pre-amp, 6AU6 Tremolo
Pre-amp, 6AU6 Tremolo
Pre-amp, 6AU6 Tremolo
Pre-amp, 6AU6 Tremolo
Pre-amp, 6AU6 Tremolo
Pre-amp, 6AU6 Tremolo
Power, Filter Cap
Power, Filter Cap
Power, Filter Cap
Power, Stand-by