

CONNECTIONS


When you have finished placing or installing all units in this system, begin making connections by following instructions on this section.

This system needs 6 kinds of connections: system connection, speaker connection, antenna connection and external unit connection, however the order of them is not important.

Never plug the AC supply lead of this system into the AC outlet until all connections are completed.

■ Making a system connection between the main control unit (TCD-AV1) and the power amplifier/subwoofer (SW-AV1)

- 1 Connect the SYSTEM CONNECTOR terminals on both units with each other by using the provided system connector cable.
 - * When connecting the system connector cable to both terminals, take notice of the directions of each SYSTEM CONNECTOR terminal's face.
- 2 Connect the AUDIO OUTPUT terminals on TCD-AV1 to the INPUT terminals on SW-AV1 by using the provided connection cord.
 - * Make sure to connect the red plug of the connection cord to the "R" (right) terminal and connect the white plug to the "L" terminal.



Caution

Be careful not to damage the **system connector cable** by placing something heavy on the cable, by fixing metal fittings on the cable, by tugging the cable, and so on. Damaging the cable will lead this system to a breakdown.