


Background is heavy aluminum foil covering the entire back of the pickguard.

You can move the middle tone control to the bridge by moving this wire to the next switch terminal.

You can have separate capacitors for each tone control by removing this wire and adding another cap. from R2 to signal return.



Drawing copyright (c) 1997, John S. Atchley