

PS-19 (146-019) PCB 052-123A

The pattern, arrow marked, must be scraped off along the dotted lines, to permit conduction through the fuse to be placed across (220V-240V only)





