



	J	U	S	E
F001	3A	3A	1A (T)	3A / 1.5A
F002 a,b	3A	3A	3.15A (F)	3A
F401	0.5A	0.5A	100mA (T)	0.5A

Note: SW 101 PHONO INPUT SELECTOR
 SW 102 TUNER
 SW 103 AUX
 SW 104 MONITOR
 SW 105 MONITOR 1, 2
 SW 106 DUBBING 1-2
 SW 107 DUBBING 2-1
 SW 108 SUBSONIC
 SW 109 HIGH CUT
 SW 110 MODE
 SW 111 LOUDNESS

*----FLEME PROOF TYPE

SW 001 POWER SW
 SW 501 SPEAKER A.
 SW 502 SPEAKER B.