


<p>MIDI RECEIVE CHANNEL</p> <p>MIDI Receive Ch C00 Omni</p>	<p><u>Omni</u> (default) – Responds to all 16 channels. <u>1-16</u> (range) – Responds to a single channel. <u>OFF</u> – Disables receive channel.</p> <p>Omni \odot 1-16 \odot OFF</p>
<p>MIDI TRANSMIT CHANNEL</p> <p>MIDI Transmit Ch C00 Off</p>	<p><u>OFF</u> (default) – Disables transmit channel. <u>1-16</u> (range) – Transmits on a single channel.</p> <p>1-16 \odot OFF</p>
<p>MIDI SYSTEM EXCLUSIVE ID NUMBER</p> <p>SysEx Device ID C00 Omni</p>	<p><u>Omni</u> (default) – Responds to all Sys Ex commands. <u>17-32</u> (range) – Responds only to Sys Ex commands for one ID.</p> <p>Omni \odot 17- 32</p>
<p>MIDI PRESET MAPPING</p> <p>MIDI#:127 Preset:C42 Map ↓ ↓</p>	<p>Any MIDI #___ = Any Preset #___ — Redirect each MIDI program change number to any preset number. Use the FX LEVEL the FX VAL2 knobs to select values (down arrows on screen point to the FX knobs).</p> <p>MIDI# 1 – 127 <u>redirected to preset# P00-P84, C00-C84, A00-A34</u></p>
<p>MIDI CONTINUOUS CONTROLLER ECHO</p> <p>CC Echo In + Out C00 Off</p>	<p><u>OFF</u> (default) – Stops the echo loop of incoming continuous controller data from mixing with the outgoing data. <u>ON</u> – Allows continuous controller data to repeatedly echo.</p> <p>OFF \odot ON</p>
<p>FACTORY PRESET RESTORE </p> <p>Press TAP key to Restore Fact Presets</p> <p>Press TAP to Verify Fact Preset Restore</p>	<p>WARNING: ALL of your presets are erased with this function. (PLAYER'S LOUNGE presets) are overwritten with FENDER CUSTOM SHOP presets.</p> <p>☞ Press the TAP key once to initiate this operation. (Press the EXIT key to cancel.)</p> <p>☞ Press the TAP key a <i>second</i> time to <u>reset all presets</u> to factory.</p> <p>Restoring Factory Presets ...</p>
<p>MIDI DUMP – UTILITY SETTINGS</p> <p>Press TAP key to MIDI Dump Utilities</p>	<p>This function will dump all UTILITY parameter settings.</p> <p>Press the TAP key once.</p>
<p>MIDI DUMP – ANY PRESET</p> <p>Press TAP key to MIDI Dump Preset C00</p>	<p>This function will dump the selected preset from the Cyber-Twin to a MIDI device. The items sent in the dump include all the parameter values for this preset.</p> <p>Select a preset with the DATA WHEEL to dump. Press the TAP once to dump.</p>
<p>MIDI DUMP – ALL PRESETS</p> <p>Press TAP key to MIDI Dump All Preset</p>	<p>This function will dump ALL presets from the Cyber-Twin to a MIDI device. The items sent in the dump include all the parameter values for every preset.</p> <p>Press TAP key once.</p>
<p>Column continues with the DEMO Mode menu, on page 44. ()</p>	