

Fender Amplifiers

Quick Reference

**This list is for U.S. and Mexico
manufactured units only**

7/16/2004

	Model		Speaker	Size	Specs	Footswitch	Specs	Cover
NS	' 59 Bassman Reissue	021-7100-000	099-4810-001	10"	8 ohm 30w Alnc.			003-7965-000
NS	' 59 Bassman Reissue ('99)	021-7100-000	005-5613-000	10"	8 ohm 30w Jensen			
	59 Bassman LTD	217-1000-010	005-5613-000	10"	8 ohm 30w Jensen			003-7965-000
	63 Reverb Unit Reissue	021-7500-000				099-4055-000	On/Off	004-8915-000
	Reverb Unit (Vintage) RCA					099-4050-000	On/Off	
	' 64 Vibroverb Custom	814-0000-000	005-9660-000	15"	8 ohm	099-4058-000	Vibrato/ Reverb	005-9753-000
	' 65 Deluxe Reverb Reissue	021-7400-000	099-4812-002	12"	8 ohm 50w Cer.	099-4058-000	Vibrato/ Reverb	004-7483-000
		OR	005-7146-000	12"	8 ohn Jensen C12K			
	57 Twin	814-0500-000	006-4418-000	12"	Alnico Weber 12"			006-4428-000
	' 65 Twin Reverb Reissue	021-7300-000	099-4812-002	12"	8 ohm 50w Cer.	099-4058-000	Vibrato/ Reverb	005-0250-000
		OR	005-7146-000	12"	8 ohm Jensen C12K			
	' 65 Twin Custom 15	217-3000-010	006-4398-000	15"	D-130 clone	099-4058-000	VIB/REV	005-0278-000
NS	94 Twin (Evil Twin)	021-4809-000	099-4812-009	12"	8 ohm 100w	099-4065-000	3 BTN GA/CH/RV	005-0284-000
NS	Acoustasonic Jr.	022-1302-000	099-4808-003	8"	8 ohm 50w	099-4053-000	Chorus	005-0249-000
		AND	004-9260-000		Piezo			
	Acoustasonic Junior DSP	221-3200-010	099-4808-003	8"	8 ohm 50w	006-2206-000	2 bttn	
		AND	004-9260-000		Piezo			
NS	Acoustasonic 30	022-1303-000	099-4808-003	8"	8 ohm HIFI	099-4053-000	Choris	
			004-9260-000		Ceramic Piezo			
	Acoustasonic 30 DSP	221-3300-010	099-4808-003	8"	8 ohm 50w	006-2206-000	2 Bttn	
			004-9260-000		Piezo			
NS	Acoustasonic Pro	022-1300-000	099-4808-003	8"	8 ohm 50w	005-1894-000	4 Button DSP	005-5032-000
		AND	004-9260-000		Piezo			
NS	Acoustasonic SFX	022-1301-000	099-4808-003	8"	8 ohm 50w			005-0246-000
		AND	099-4810-004	10	8 ohm			
		AND	004-9260-000		Ceramic Piezo			
	Acoustasonic SFX II	221-3100-010	005-9883-000	6"	8ohm 50w	005-9871-000	3 bttn	
		AND	005-9773-000	8"	8ohm 50w			
		AND	004-9260-000		Piezo			

Fender Amplifiers

Quick Reference

	Model		Speaker	Size	Specs	Footswitch	Specs	Cover
NS	Amp Can	022-1200-000	005-0543-000	6"	4 ohm 30w			
	Amp Can	023-1200-000						
NS	Automatic GT	022-6300-000	099-4812-005	12"	8 ohm 75w	099-4057-000	Channel/ Chorus	
NS	Automatic SE	022-6400-000	099-4812-005	12"	8 ohm 75w	099-4057-000	Channel/ Chorus	
NS	Bandmaster Head (Vintage)					099-4050-000	Vibrato	
NS	Bandmaster/Bassman 2-12		099-4812-002	12"	8 ohm 50w Cer.			004-1537-000
NS	Bass Breaker 59 bassman	082-2100-000	005-8056-000	12"	70w T4617 Celestio			003-7965-000
	Bassman 25	022-4501-000	003-8657-000	10"	8 ohm			
NS	Bassman 60	022-4502-000	099-4812-004	12"	8 ohm			
		AND	005-3641-000		Piezo			
NS	Bassman 100	022-4503-000	099-4815-001	15"	4 ohm 100 w			005-5551-000
		AND	005-3641-000		Piezo			
NS	Bassman 200	022-4504-000	099-4815-004	15"	4ohm 150w			005-7516-000
		AND	004-8847-000		8 ohm horn			
	Bassman 300	021-3302-010				005-7745-000	Ch Mix/Geq/Comp	005-4914-000
NS	Bassman 400	022-4505-000	099-4810-005	10"	8 ohm	005-5852-000	EQ	005-5564-000
		AND	004-8847-000		8 ohm Horn			
	Bassman 1200	021-3300-010				005-7745-000	Ch Mix/Geq/Comp	
NS	Blues Deluxe	021-3102-000	099-4812-002	12"	8 ohm 50w Cer.	099-4052-000	Channel	004-7485-000
NS	Blues DeVille 212	021-3100-000	099-4812-002	12"	8 ohm 50w Cer.	099-4056-000	Channel/ Reverb	004-8916-000
NS	Blues DeVille 410	021-3101-000	099-4810-002	10"	8 ohm 30w Cer.	099-4056-000	Channel/ Reverb	003-7965-000
NS	Blues Junior Tweed	021-3105-000	099-4812-002	12"	8 ohm 50w Cer.	099-4054-000	Fat	005-0279-000
	Blues Junior Black	021-3205-000	099-4812-002	12"	8 ohm 50w Cer.	099-4054-000	Fat	005-4912-000
	Blues Jr TWD LQR	021-3205-700	005-7065-000	12"	8 ohm Jensen C12N	099-4054-000	Fat	
NS	Bronco	021-3104-000	099-4808-002	8"	8 ohm 25w			
NS	Bullet/Bullet Reverb	022-6705-0??	099-4808-002	8"	8 ohm 25w			
NS	Bullet 15 DSP	226-7700-020	099-4808-002	8"	8 ohm 25w			
NS	Bullet 15 DSP	236-7700-000						
	Bullet 150	236-7700-03x		8"	15w			
NS	BXR 15	022-4402-000	099-4808-002	8"	8 ohm 25w			
NS	BXR 60	022-4404-000	099-4812-004	12"	8 ohm 75w			004-8913-000
NS	BXR 100	022-4401-000	099-4815-001	15"	4 ohm 100w			004-1539-000
NS	BXR 115B Enclosure	021-1670-000	099-4815-005	15"	8 ohm 150w			
NS	BXR 200	022-4405-000	099-4815-004	15"	4 ohm 150w	099-4053-000	Chorus	005-0281-000

Fender Amplifiers

Quick Reference

	Model		Speaker	Size	Specs	Footswitch	Specs	Cover
NS	BXR 210 Enclosure	021-1672-000	099-4810-007	10"	8 ohm			
NS	BXR 300c	022-4100-000	099-4815-005	15"	8 ohm 150w			003-7967-000
NS	BXR 410 Enclosure	021-1671-000	099-4810-005	10"	8 ohm			
NS	Champ (Old)		099-4808-001	8"	4 ohm 15w Cer.			
NS	Champ 25SE	021-6600-000	099-4812-005	12"	8 ohm 75w	099-4056-000	Channel/ Reverb	004-0155-000
NS	Champion 30	022-6703-010	099-4810-003	10"	8 ohm 30w	099-4052-000	Channel	004-1529-000
NS	Champion 30 DSP	226-7300-020	099-4810-003	10"	8 ohm 30w	099-4052-000	Channel	004-1529-000
NS	Champion 30 DSP	236-7300-020	099-4810-003	10"	8 ohm 30w	099-4052-000	Channel	004-1529-000
	Champion 300	236-7300-030		10"	30W	099-4052-000	Channel	
NS	Champion 110	022-6703-000	099-4810-003	10"	8 ohm 30w	099-4052-000	Channel	004-1529-000
NS	Concert ('93)	021-4802-000	099-4812-002	12"	8 ohm 50w Cer.	099-4064-000	Channel/ Gain/ Reverb	004-1532-000
ch	Custom Vibrolux Reverb	021-5100-000	099-4810-001	10"	8 ohm 30w Alnc.	099-4058-000	Vibrato/ Reverb	003-7966-000
	Custom Vibrolux Reverb	021-5100-000	005-5613-000	10"	8 ohm Jensen P10R	099-4058-000	Vibrato/Reverb	
	Cyber Champ	229-0300-000	005-4420-000	12"	8 ohm G12T-100			
	Cyber Deluxe	022-9001-000	005-4420-000	12"	8 ohm G12T-100	005-7219-000	4 Btn DSP	005-7671-000
NS	Cyber Foot Controler	022-9100-000						099-1553-000
	Cyber Foot Controler	23-91000-000						
NS	Cyber Twin	022-9000-000	005-4420-000	12"	8 ohm G12T-100	005-7219-000	4 Button DSP	005-7518-000
		AND				005-7172-000	1Button FX Kill	
NS	Cyber Twin Head	022-9002-000				005-7219-000	4 Button DSP	005-7652-000
		AND				005-7172-000	1Button FX Kill	
	Cyber Twin SE	229-0000-010				005-7219-000	4 Button DSP	
		AND				005-7172-000	1Button FX Kill	
NS	Deco Tone (Blues Jr. Plastic	021-2002-000	099-4812-002	12"	8 ohm 50w	099-4054-000	Fat	
NS	Deluxe 90	022-6702-020	005-4421-000	12"	4 ohm 100w G12T	099-4062-000	Channel/ Gain-More Gain	002-9881-000
NS	Deluxe 90 DSP	226-7200-030	005-4421-000	12"	4 ohm 100w G12T	005-7473-000	Ch/Efx/(Dr/Mdr)	002-9881-000
	Deluxe 900	226-7200-040	005-4421-000	12"	Cel G12T100	006-4465-000	3 BTN DLX 900	
NS	Deluxe 112	022-6702-000	099-4812-005	12"	8 ohm 75w	099-4056-000	Channel/ Reverb	002-9881-000
NS	Deluxe 112 Plus	022-6702-010	099-4812-008	12"	4 ohm 100w	099-4056-000	Channel/ Reverb	002-9881-000
	Deluxe Reverb (Vintage)		099-4812-001	12"	8 ohm 30w Alnc.	099-4051-000	Vibrato/ Reverb	
NS	Dual Professional	081-1005-000	099-4812-003	12"	8 ohm 60w 'V30'	099-4060-000	Vibrato/ Channel	004-8918-000
NS	Frontman 15	022-1500-000	099-4808-002	8"	8 ohm 25w			
NS	Frontman 15R	022-1501-000	099-4808-002	8"	8 ohm 25w			
NS	Frontman 15B	022-1503-000	099-4808-002	8"	8 ohm 25w			

Fender Amplifiers

Quick Reference

	Model		Speaker	Size	Specs	Footswitch	Specs	Cover	
NS	Frontman 25B	022-1504-000	003-8657-000	10"	8 ohm				
NS	Frontman 25R	022-1502-000	099-4810-003	10"	8 ohm 30w	099-4052-000	Channel		
	Frontman 15G	Indonesia	023-1500-000						
	Frontman 15R	Indonesia	023-1501-000						
	Frontman 25R	Indonesia	023-1502-000						
NS	Frontman 15B	Indonesia	023-1503-000						
NS	Frontman 25B	Indonesia	023-1504-000						
NS	Frontman 60B	Indonesia	023-1505-000						
	FM65R		231-6000-000	65W RMS 8	12"	8 ohm sp. Design		1 Btn Drive / Optional	002-9883-000
				006-2679-000	?		099-4052-000	???	
	FM212R		231-6500-000	100W RMS 4	12"	8 ohm sp. Design	???	2 Btn Drive/More/ included	002-9885-000
				062-803-000	?		099-4062-000		
NS	HOT	022-6100-000	099-4810-003	10"	8 ohm 30w				
	Hot Rod Deluxe		021-3202-000	099-4812-002	12"	8 ohm 50w Cer.	099-4062-000	Channel/ Gain-More Gain	005-0696-000 inc
	Hot Rod DeVille 212		021-3200-000	099-4812-002	12"	8 ohm 50w Cer.	099-4062-000	Channel/ Gain-More Gain	005-0698-000 inc
	Hot Rod DeVille 410		021-3201-000	099-4810-002	10"	8 ohm 30w Cer.	099-4062-000	Channel/ Gain-More Gain	005-0697-000 inc
NS	JAM	022-6200-000	099-4812-005	12"	8 ohm 75w				
NS	KXR 60	022-8500-000	099-4812-004	12"	8 ohm 75w				
			AND	004-9260-000		Piezo			
NS	KXR 100	022-8501-000	099-4815-001	15"	4 ohm 100w			005-0282-000	
			AND	002-8813-000		Peizo Dual			
NS	KXR 200	022-8502-000	099-4815-003	15"	4 ohm 150w			005-0283-000	
			AND	002-8813-000		Peizo Dual			
NS	M-80	022-5900-010	099-4812-005	12"	8 ohm 75w	099-4052-000	Channel	003-7962-000	
NS	M-80 Bass	022-4200-010	099-4815-005	15"	8 ohm 150w	099-4053-000	Chorus	004-1598-000	
NS	M-80 Chorus	022-5905-010	099-4812-005	12"	8 ohm 75w	099-4057-000	Channel/ Chorus	003-7964-000	
	Metalhead								
	MH 412 SL								
	MH 412 ST								
	Passport P10		069-1110-000	005-7830-000					
	Passport P10W		069-1120-00X	005-7830-000					
	Passport P80 (W)		069-1003-000						
	Passport 150		069-1006-003	007-0553-000	6.5"	4 ohm		007-0589-000 inc	
	Passport 250		069-1002-003	007-0309-000	6.5"	8 ohm 40w		00-70325-000 inc	

Fender Amplifiers

Quick Reference

Model		Speaker	Size	Specs	Footswitch	Specs	Cover
Passport 150 PD	069-2005-003	007-0371-000		8 ohm			007-0589-000
	AND	007-0370-000		4 ohm Tweeter			
Passport 250 PD	069-2001-003	007-0431-000		4 ohm			00-70325-000
	AND	007-0370-000		4 ohm tweeter			
NS Performer 1000	022-6800-000	099-4812-007	12"	8 ohm 80w	099-4064-000	Channel/ Gain/ Reverb	002-9888-000
NS Performer 650	022-6805-000	099-4812-005	12"	8 ohm 75w	099-4056-000	Channel/ Reverb	002-9881-000
NS Power Chorus	022-5800-000	099-4812-005	12"	8 ohm 75w		NO LONGER AVAILABLE	002-9885-000
NS Princeton 65	022-6704-020	099-4812-005	12"	8 ohm 75w	099-4052-000	Channel	002-9883-000
NS Princeton 65 DSP	226-7400-030	099-4812-005	12"	8 ohm 75w	005-7664-000	CH/FX	002-9883-000
Princeton 650	226-7400-040	006-4777-000	12"	Cel G12T100	005-7664-000	2-BTTN CH/FX	
NS Princeton 112	022-6704-000	099-4812-005	12"	8 ohm 75w	099-4056-000	Channel/ Reverb	002-9883-000
NS Princeton Chorus	022-5700-010	099-4810-004	10"	8 ohm 30w	099-4057-000	Channel/ Chorus	002-9888-000
NS Princeton Chorus DSP	022-5700-020	099-4810-004	10"	8 ohm	005-5592-000	3-btn PRCR DSP	002-9888-000
NS Pro Junior Tweed	021-3103-000	099-4810-002	10"	8 ohm 30w Cer.			004-7484-000
Pro Junior Black	021-3203-000	099-4810-002	10"	8 ohm 30w Cer.			005-4913-000
NS Pro 185	022-5600-010	099-4812-009	12"	8 ohm 100w	099-4063-000	Channel/ Reverb/ Boost	002-9885-000
NS Pro Reverb (Old)		099-4812-001	12"	8 ohm 30w Alnico	099-4051-000	Vibrato/ Reverb	
Pro Tube 65 Super Reverb	021-7600-000	005-5613-000	10"	8 ohm Jensen P10R	099-4058-000	Vib/ Rev	
Pro Tube Concert	021-5900-000	099-4810-002	10"	8 ohm 30w cer.	005-7025-000	4 BTN	005-7358-000
Pro Tube Twin	021-5700-000	099-4812-002	12"	8 ohm 50w Vint. Cer	005-7025-000	4 btn	005-7533-000
Pro Tube Reverb	021-5500-000	005-7065-000	12"	8 ohm Jensen C12N	005-7025-000	4 btn	005-7532-000
NS Prosonic Combo	021-3001-(10	099-4810-006	10"	8 ohm 60w Cel.	099-4061-000	Channel/ Reverb	005-0696-000
NS Prosonic Head	021-2007-(10				099-4054-000	Channel	005-0286-000
NS Roc Pro 700	022-6806-000	099-4812-005	12"	8 ohm 75w	099-4056-000	Channel/ Reverb	002-9881-000
NS Roc Pro 1000	022-6808-000	099-4812-007	12"	8 ohm 80w	099-4064-000	Channel/ Gain/ Reverb	002-9888-000
Rumble 15 combo	231-5300-010	006-2761-000	8"				
Rumble 25 combo	231-5400-010	006-2762-000	10"				
Rumble 60 combo	231-5500-010	006-2763-000	12"	8 ohm			
Rumble 100 combo	231-5600-010	006-2764-000	15"	4 ohm			
NS Rumble Bass Head	081-2100-000				099-4054-000	Channel	
NS Rumble Bass 410 Encl.	081-3100-000	004-9546-000	10"	16 ohm 59 oz			
NS Rumble Bass 410 Sub Encl.	081-3101-000	004-9547-000	10"	4 ohm 59 oz			
NS SFX Keyboard	022-8503-000	005-3614-000	10"	8 ohm			
	AND	004-7539-000	12"	8 ohm 75w			

Fender Amplifiers

Quick Reference

	Model		Speaker	Size	Specs	Footswitch	Specs	Cover
		AND	004-9260-000		Piezo			
NS	Satellite SFX	022-2001-000	099-4812-008	12"	4 ohm 100w	005-3586-000	Effects	005-0247-000
NS	Stage 100	022-6700-010	005-4420-000	12"	8 ohm 100w G12T	099-4062-000	Channel/ Gain-More Gain	002-9888-000
NS	Stage 100 DSP	226-7000-020	005-4420-000	12"	8 ohm 100w G12T	005-7601-000	4 BTN STAGE DSP	002-9888-000
NS	Stage 100 dsp Head	226-9000-010				099-4062-000	Channel/ Gain-More Gain	
	Stage 1000	226-7000-030		12"	Cel G12T100	006-2191-000		
NS	Stage 112SE	022-6700-000	099-4812-009	12"	8 ohm 100w	099-4056-000	Channel/ Reverb	002-9888-000
NS	Stage 160	022-6800-010	005-4420-000	12"	8 ohm 100w G12T	099-4062-000	Channel/ Gain-More Gain	002-9885-000
NS	Stage 160 DSP	226-8000-020	005-4420-000	12"	8 ohm 100w G12T	005-7601-000	4 BTN STAGE DSP	002-9885-000
	Stage1600	226-8000-030		12"	Cel G12T100	006-2191-000		
	Steel-King	228-9500-000	006-4398-000	15'	4ohm Emin	006-4544-000	3 btnn Rev/FXI/Tuner mute	
	Super Reverb (65) Pro Tube	021-7600-000	005-5613-000	10"	8 ohm Jensen P10R	099-4058-000	Vibrato/Reverb	004-1533-000
NS	Super Amp ('93)	021-4806-000	099-4810-001	10"	8 ohm 30w Alnc.	099-4064-000	Channel/ Gain/ Reverb	004-1533-000
NS	The Twin (Red Knob)	021-6200-010	099-4812-009	12"	8 ohm 100w	099-4056-000	Channel/ Reverb	005-0284-000
NS	Tonemaster Head	081-2000-000				099-4054-000	Channel	004-1536-000
NS	Tonemaster Black	811-0000-000						
NS	Tonemaster 212 Enclosure	081-3000-000	099-4812-006	12"	8 ohm 80w G12-80			004-1537-000
NS	Tonemaster 212 V30 Encl.	081-3003-000	099-4812-003	12"	8 ohm 60w 'V30'			004-1537-000
	Tonemaster 212B Black	813-0400-010	004-7279-000	12"	8 ohm T3903			
NS	Tonemaster 412 Enclosure	081-3001-000	099-4812-003	12"	8 ohm 60w 'V30'			004-1538-000
	Tonemaster 412 Enc Black							
NS	Two Tone (Blues Jr.)	082-2000-000	099-4810-002	10"	8 ohm 30w Cer.	099-4054-000	Fat	
		AND	099-4812-002	12"	8 ohm 50w			
NS	Twin Reverb (Vintage)		099-4812-002	12"	8 ohm 50w Cer.	099-4051-000	Vibrato/ Reverb	
NS	Ultimate Chorus	022-6701-010	099-4812-005	12"	8 ohm 75w	099-4057-000	Channel/ Chorus	002-9885-000
	Ultimate Chorus DSP	022-6701-020	099-4812-005	12"	8 ohm 75w	005-5592-000	3 BTN PRCR DSP	002-9885-000
NS	Vibrasonic Reverb	021-5200-000	099-4815-002	15"	4 ohm 100w	099-4058-000	Vibrato/ Reverb	005-0278-000
NS	Vibro-Champ		099-4808-001	8"	4 ohm 15w			
NS	Vibro-King Blond	081-1000-000	099-4810-001	10"	8 ohm 30w Alnc.	099-4059-000	Vibrato/ Fat	004-1535-000
	Vibro King Black	811-0000-010	005-5613-000	10"	8 ohm Jensen P10R	099-4059-000	Vibrato/ Fat	
NS	Vibro-King 212 Enclosure	081-3004-000	099-4812-003	12"	8 ohm 60w 'V30'			048-9817-000
NS	Vibro-King Custom NAMM spc	811-0000-100	005-5613-000	10"	8 ohm Jensen P10R	099-4059-000	Vibrato/ Fat	
	VK 212B	813-0400-010	004-7279-000	12"	8 ohm			
NS	Vibroverb ('63 Reissue)	021-7200-000	003-7076-000	10"	8 ohm	099-4058-000	Vibrato/Reverb	003-7966-000

Fender Amplifiers

Quick Reference

	Model		Speaker	Size	Specs	Footswitch	Specs	Cover
Sunn (new) 1998 to 2003								
NS	Model T	021-3303-000				005-7664-000	2-BTTN CH/FX	005-0248-000
NS	T50C	021-3304-000	005-3982-000	12"	16 OHM 100W	005-5771-000	3 BTN SUNN	005-5128-000
NS	Model T 412 Enclosure	021-1675-000	005-3982-000	12"	16 OHM T3760			005-4910-000
NS	T50C 112 Enclosure	021-1676-000	005-3982-000	12"	16 OHM T3760			005-5568-000
NS	Sunn 1200S	021-3300-000				005-3895-000	3 BTN SUNN BASS	
NS	Sunn 300T	021-3302-000				005-3895-000	3 BTN SUNN BASS	005-4914-000
NS	410 Bass Enclosure	021-1673-000	099-4810-005	10"	8 OHM 75W			005-4909-000
		AND	004-8847-000		Foster 8 OHM			
NS	215 Bass Enclosure	021-1674-000	005-1863-000	15"	16 OHM			005-4911-000
	400 Pro combo	224-5500-010	005-7982-000	10"	8ohm Cast	005-5852-000	EQ	
		AND	004-8847-000		Foster 8 OHM			
	800 Pro Head	214-6800-000				005-852-000	EQ	
	Bassman 115	021-1670-010	099-4815-005	15"	8 ohm 150w			005-5541-000
NS	Bassman 215	22-17300-000	005-1863-000	15"	16 ohm			005-4911-000
	Bassman 410H	021-1671-010	099-4810-005	10"	8 ohm 75w			005-5567-000
		AND	004-8847-000		8 ohm Horn			
	Bassman 410 Pro SL	221-7000-000	005-7982-000	10"	8 ohm			
		AND	004-8847-000		8 ohm Foster			
NS	Bassman Pro 410ST	221-7100-000						
		AND	004-8847-000		8 ohm Foster			
	Bassman 410 Pro ST	221-7100-000	005-7982-000	10"	8 ohm cast			
		AND	004-8847-000		8 ohm Foster			
NS	Bassman 810 Pro	221-7200-000						
		AND	004-8847-000		8 ohm Foster			
	810 PRO Cabinet	221-7200-000	005-7982-000	10"	8 ohm cast			
		AND	004-8847-000		8 ohm Foster			
NS	DT 112	021-1664-000	005-4420-000	12"	8 ohm G12T-100			
NS	DT 412	021-1665-000	005-4420-000	12"	8 ohm G12T-100			004-1534-000

