3. Measuring Circuit



Fig. 3-1

* Use the load resistor with tolerance within the range of ±5 %.