



ELECTRONIC PORTABLE ORGAN
MOD. COMPACT
BY FARFISA



FARFISA S.P.A. - P.O. BOX 204 - ANCONA

Some explanation on schematics

SE - 10: Operating schematics

The schematics show the general principles, which are the following ones:

a) The signals are originated by oscillators G 10. Each one of them produces all the frequencies of same name (i. e. G 10 - C produces all Cs, G 10 - A produces all As, etc.).

b) The Vibrato is obtained operating directly on the oscillators of the various notes.

c) Every key has three contacts: the lower one operates on 16' frequencies, the medium one operates on 8' frequencies, the upper one operates on 4' frequencies.

d) All the contacts related to every octave, C-B, for 16' or 8' or 4', have common ends for connection to filters; these ends are represented by common bars and each one them is connected by means of a shielded cable to a series of switches operated by the MTB ON/OFF tab.

e) The MTB switches are meant to convey the signals to the tone stops when the MTB tab is in OFF position. In this case, inserting one tone stop (or several stops at the same time), the signals are conveyed to filter FD 10, where part of the signals is blended and then conveyed to filter FA 10 for the formation of the sharp tones (oboe, trumpet, strings).

The signals proceeding from filter FA 10 return to the tone stops and through the inserted tab, they are conveyed to the L.F. preamplifier. At the same time, in the filter FD 10, an attenuation of the higher harmonics, interesting the signals conveyed to the low pass filter, takes place, giving way to an output of sweet tune signals, ready to be conveyed, through the special tone stops (bass, flute), to the L. F. preamplifier.

f) When MTB is inserted, the switches convey the signals proceeding from the common bars to filter FD 10 through MTB stops (16'-8'-4'). The total blending of signals in FD 10 is then conveyed directly to the special in take of MTB, where the filtered signals, available at the outlet No. 10 of FD 10 (sweet tune) are conveyed to the outlet of MTB.

The L.F. preamplifier is connected only to the outlet of MTB and amplifies therefore only the signals conveyed to this device through 16'-8'-4' stops (Green tabs) with the exclusion of the tone stops (white tabs).

g) When « All Booster » is inserted, the signals proceeding from the common bars are permanently conveyed, at constant level, to filter FD-10 through MTB stops 16', 8', 4'.

SE - II: Simplified keying schematics for Treble and Manual Bass.

It shows the wiring of the various notes, making reference to one note only (A).

SE - 12: Circuit diagram of Treble registers

The drawing reports the connections interesting the tone stops and the connections between the registers and the filters.

In the left top corner, framed in a square, it is shown the schematic diagram of MTB device.

SE - 13: Circuit diagram of Pedal registers, Vibrato and Reverb.

The drawing showing the Manual Bass and the Pedalboard stops indicates the potentiometers for the volume regulation of single notes, while the drawing related to Vibrato and Reverb shows Potentiometer R 536 for the regulation of the time of Reverberation.

SE - 14: Schematics of Master oscillators (G 10), filters (FD 10), (FA 10), Vibrato circuit and Pedal amplifier (PS 10).

The schematics show the values of all components assembled in the printed circuits for repair purpose.

SE - 15: Circuit diagram of Power Supply, Preamplifier and Reverb.

Complete electric schematics, showing the voltage rating and the features of electric components. Almost in the centre of the page it is indicated the Swell Pedal photoresistor operating as volume control.

REAR VIEW

From serial-number A 68 the position of the generator circuit-boards is as follows:

A partire dalla commessa A 68 la posizione delle piastre dei generatori è la seguente:

A	- LA	C sharp	- DO d	F	- FA
E	- MI	G sharp	- SOL d	C	- DO
B	- SI	D sharp	- RE d	G	- SOL
F sharp	- FA d	A sharp	- LA d	D	- RE

Fig. E




Fig. F




Fig. H






Fig. G





(See schematics SE-15 (CompaCt) SE-16 (Rhapsody))



DWG NO	SE-10	Ref
CAMERANO - ANCONA -	ELECTRONIC ORGANS Mod. "COMPACT" and "RHAPSODY"	46/6
Operating schematics		

FARFISA SPA
CAMERANO - ANCONA -

ELECTRONIC ORGANS Mod. "COMPACT"
and "RHAPSODY"
Operating schematics



PIN No	TONE	COLOR CODE
4	C	GREY
5	C#	WHITE
6	D	TRANSPARENT
7	D#	PINK
8	E	BLACK
9	F	BROWN
10	F#	RED
11	G	ORANGE
12	G#	YELLOW
13	A	GREEN
14	A#	LIGHT BLUE
15	B	BLUE

① ÷ ⑫ = Shielded cables for connection from common bars to Multi-tone switches
 □ = Multi-tone Booster switches (see schematics treble registers SE-12)


FARFISA SPA
 CANTERANO - ANCONA -
SE-11 ELECTRONIC ORGAN Mod. "COMPACT"
 Simplified Keying schematics for Treble and
 Manual Bass

DWG. No.

SE-11

Off


46/6



(1) ÷ (12) = Shielded cables for connection to common bars of contacts
 1÷12 (FD10) = Filter output round tones
 1+11 (FA10) = Filter output sharp tones

DWG No	SE-35	DWG No	56/4
CAMERANO - ANCONA -	ELECTRONIC ORGAN Mod. "COMPACT"	Registers circuit diagram	


FARFISA SPA
 CAMERANO - ANCONA -
 ELECTRONIC ORGAN Mod. "COMPACT"
 Treble registers circuit diagram




PRINTED CIRCUIT G 10 - TONE GENERATOR C ÷ B

DWG No **SE - 14**


46 / 6




	C o	C ⁴ o	C1 a + C ⁴ 1 a	C1 b + C ⁴ 1 b	C2 a + C ⁴ 2 a	C2 b + C ⁴ 2 b	C3 a + C ⁴ 3 a	C3 b + C ⁴ 3 b	C4 a + C ⁴ 4 a	C4 b + C ⁴ 4 b	C5 a + C ⁴ 5 a	C5 b + C ⁴ 5 b
C DO	5,6 n	0,82 n	3,3 n	3,9 n	6,6 n	8,2 n	13,6 n	18 n	28 n	33 n	54 n	68 n
C # DO#	15 n	—	6,5 n	8,2 n	13,4 n	18 n	27 n	33 n	52 n	68 n	104 n	120 n
D RE	12 n	1,5 n	6 n	6,8 n	12 n	15 n	25 n	33 n	50 n	56 n	98 n	120 n
D # RE#	12 n	—	5,7 n	6,8 n	11,3 n	15 n	23 n	27 n	46 n	56 n	92 n	120 n
E MI	8,2 n	1 n	5,5 n	6,8 n	11 n	15 n	22 n	27 n	43 n	56 n	84 n	100 n
F FA	8,2 n	—	5 n	5,6 n	10 n	12 n	21 n	27 n	41 n	47 n	82 n	100 n
F # FA#	6,8 n	1 n	4,6 n	5,6 n	9,2 n	12 n	18 n	22 n	37 n	47 n	74 n	100 n
G SOL	5,6 n	0,82 n	4,3 n	5,6 n	8,6 n	10 n	18 n	22 n	36 n	47 n	72 n	82 n
G # SOL#	10 n	—	3,8 n	4,7 n	8,2 n	10 n	17 n	22 n	35 n	47 n	69 n	82 n
A LA	8,2 n	1,5 n	3,6 n	4,7 n	7,8 n	10 n	16 n	22 n	33 n	39 n	64 n	82 n
A # LA#	8,2 n	—	3,4 n	3,9 n	7,2 n	8,2 n	16 n	22 n	29 n	39 n	59 n	68 n
B SI	6,8 n	1 n	3,1 n	3,9 n	6,2 n	8,2 n	13,5 n	18 n	28 n	33 n	56 n	68 n



Printed circuit FD 10
round tones filter



Printed circuit FA 10
sharp tones filter



Printed circuit PS 10
vibrato and amplifier
of pedal

